



ABN 43 064 478 842

> 231 osborne avenue clayton south, vic 3169
PO box 1548, clayton south, vic 3169
t 03 9265 7400 f 03 9558 0875
freecall 1800 680 680
www.tmgtestequipment.com.au

Test & Measurement

- > sales
- > rentals
- > calibration
- > repair
- > disposal

Complimentary Reference Material

This PDF has been made available as a complimentary service for you to assist in evaluating this model for your testing requirements.

TMG offers a wide range of test equipment solutions, from renting short to long term, buying refurbished and purchasing new. Financing options, such as Financial Rental, and Leasing are also available on application.

TMG will assist if you are unsure whether this model will suit your requirements.

Call TMG if you need to organise repair and/or calibrate your unit.


If you click on the "Click-to-Call" logo below, you can call us for FREE!

TMG Corporate Website

TMG Products Website



Click-to-Call
TMG Now



Disclaimer:

All trademarks appearing within this PDF are trademarks of their respective owners.

WARNING

Death, serious injury, or fire hazard could result from improper connection of this instrument. Read and understand this manual before connecting this instrument. Follow all installation and operating instructions while using this instrument.

Connection of this instrument must be performed in compliance with the National Electrical Code (ANSI/NFPA 70-2002) of USA and any additional safety requirements applicable to your installation.

Installation, operation, and maintenance of this instrument must be performed by qualified personnel only. The National Electrical Code defines a qualified person as “one who has the skills and knowledge related to the construction and operation of the electrical equipment and installations, and who has received safety training on the hazards involved.”

Qualified personnel who work on or near exposed energized electrical conductors must follow applicable safety related work practices and procedures including appropriate personal protective equipment in compliance with the Standard for Electrical Safety Requirements for Employee Workplaces (ANSI/NFPA 70E-2000) of USA and any additional workplace safety requirements applicable to your installation.

Power Platform[®] 4300

TASKCard[®] PQLite

USER'S GUIDE

Original Issue - September 15, 1995

Revision A - January 15, 1997

Revision B - May 1, 2002



DRANETZ - BMI
1000 New Durham Road
Edison, New Jersey 08818-4019

Part Number OM-4300-PQLITE

Published by Dranetz-BMI
1000 New Durham Road
Edison, NJ 08818-4019 USA
Telephone: 1-800-372-6832 or 732-287-3680
Fax: 732-248-1834
Web site: www.dranetz-bmi.com

Copyright © 1995, 1997, 2002 Dranetz-BMI
All rights reserved.

No part of this book may be reproduced, stored in a retrieval system, or transcribed in any form or by any means—electronic, mechanical, photocopying, recording, or otherwise—without prior written permission from the publisher, Dranetz-BMI, Edison, NJ 08818-4019.

Printed in the United States of America.

P/N OM-4300-PQLITE Rev. B

ADVERTENCIA

Una conexión incorrecta de este instrumento puede producir la muerte, lesiones graves y riesgo de incendio. Lea y entienda este manual antes de conectar. Observe todas las instrucciones de instalación y operación durante el uso de este instrumento.

La conexión de este instrumento debe ser hecha de acuerdo con las normas del Código Eléctrico Nacional (ANSI/NFPA 70-2002) de EE. UU., además de cualquier otra norma de seguridad correspondiente a su establecimiento.

La instalación, operación y mantenimiento de este instrumento debe ser realizada por personal calificado solamente. El Código Eléctrico Nacional define a una persona calificada como "una que esté familiarizada con la construcción y operación del equipo y con los riesgos involucrados."

AVERTISSEMENT

Si l'instrument est mal connecté, la mort, des blessures graves, ou un danger d'incendie peuvent s'en suivre. Lisez attentivement ce manuel avant de connecter l'instrument. Lorsque vous utilisez l'instrument, suivez toutes les instructions d'installation et de service.

Cet instrument doit être connecté conformément au National Electrical Code (ANSI/NFPA 70-2002) des Etats-Unis et à toutes les exigences de sécurité applicables à votre installation.

Cet instrument doit être installé, utilisé et entretenu uniquement par un personnel qualifié. Selon le National Electrical Code, une personne est qualifiée si "elle connaît bien la construction et l'utilisation de l'équipement, ainsi que les dangers que cela implique".

WARNUNG

Der falsche Anschluß dieses Gerätes kann Tod, schwere Verletzungen oder Feuer verursachen. Bevor Sie dieses Instrument anschließen, müssen Sie die Anleitung lesen und verstanden haben. Bei der Verwendung dieses Instruments müssen alle Installation- und Betriebsanweisungen beachtet werden.

Der Anschluß dieses Instruments muß in Übereinstimmung mit den nationalen Bestimmungen für Elektrizität (ANSI/NFPA 70-2002) der Vereinigten Staaten, sowie allen weiteren, in Ihrem Fall anwendbaren Sicherheitsbestimmungen, vorgenommen werden.

Installation, Betrieb und Wartung dieses Instruments dürfen nur von Fachpersonal durchgeführt werden. In den nationalen Bestimmungen für Elektrizität wird ein Fachmann als eine Person bezeichnet, welche "mit der Bauweise und dem Betrieb des Gerätes sowie den dazugehörigen Gefahren vertraut ist."

Safety Summary

Definitions

WARNING statements inform the user that certain conditions or practices could result in loss of life or physical harm.

CAUTION statements identify conditions or practices that could harm the Power Platform, its data, other equipment, or property.

NOTE statements call attention to specific information.

Symbols

The following International Electrotechnical Commission (IEC) symbols are marked on the top and rear panel in the immediate vicinity of the referenced terminal or device:



Caution, refer to accompanying documents (this manual).



Direct current (DC) operation of the terminal or device.



Power Switch

Definiciones

Las ADVERTENCIAS informan al usuario de ciertas condiciones o prácticas que podrían producir lesiones mortales o daño físico.

Las PRECAUCIONES identifican condiciones o prácticas que podrían dañar la Power Platform, sus datos, otros equipos o propiedad.

Las NOTAS llaman la atención hacia la información específica.

Símbolos

Los siguientes símbolos de la Comisión Internacional Electrotécnica (IEC) aparecen marcados en el panel superior y el posterior inmediatos al terminal o dispositivo en referencia:



Precaución, consulte los documentos adjuntos (este manual).



Operación de corriente continua (CC) del terminal o dispositivo.



Interruptor de encendido

Continued on next page

Safety Summary, Continued

Définitions

Les messages d'AVERTISSEMENT préviennent l'utilisateur que certaines conditions ou pratiques pourraient entraîner la mort ou des lésions corporelles.

Les messages de MISE EN GARDE signalent des conditions ou pratiques susceptibles d'endommager "Power Platform", ses données, d'autres équipements ou biens matériels.

Les messages NOTA attirent l'attention sur certains renseignements spécifiques.

Symboles

Les symboles suivants de la Commission électrotechnique internationale (CEI) figurent sur le panneau arrière supérieur situé à proximité du terminal ou de l'unité cité:



Mise en garde, consultez les documents d'accompagnement (ce manual).



Fonctionnement du terminal ou de l'unité en courant continu (CC).



Interrupteur de tension

Definitionen

WARNUNGEN informieren den Benutzer darüber, daß bestimmte Bedingungen oder Vorgehensweisen körperliche oder tödliche Verletzungen zur Folge haben können.

VORSICHTSHINWEISE kennzeichnen Bedingungen oder Vorgehensweisen, die zu einer Beschädigung von Power Platform, seiner Daten oder anderer Geräte bzw. von Eigentum führen können.

Symbole

HINWEISE machen auf bestimmte Informationen aufmerksam.
Die folgenden Symbole der Internationalen Elektrotechnischen Kommission (International Electrotechnical Commission; IEC) befinden sich auf der Abdeck- und Seitenplatte unmittelbar am betreffenden Terminal oder Gerät.



Vorsichtshinweis, siehe Begleitdokumente (dieses Handbuch).



Gleichstrombetrieb im Terminal oder Gerät.



Netzschalter

Safety Summary, Continued

Safety precautions

The following safety precautions must be followed whenever any type of voltage or current connection is being made to the 4300.

- Wear proper Personal Protective Equipment, including safety glasses and insulated gloves when making connections to power circuits.
- Hands, shoes and floor must be dry when making any connection to a power line.
- Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.
- Set the 4300 power switch to Off.
- Before connecting to electric circuits to be monitored, open their related circuit breakers or disconnects. DO NOT install any connection of the 4300 to live power lines.
- Connections must be made to the 4300 first, then connect to the circuit to be monitored.

These safety precautions are repeated where appropriate throughout this manual.

CHANGE STATUS

Change No. 0: Original Issue: September 15, 1995.

Change No. 1: Revision A: January 15, 1997. Incorporating ECO 3313, 3458, 3459, 3499.

Change No. 2: Revision B: May 1, 2002. Incorporating ECO 16203, 16258, 16273, 16497, 16592, 16594, 16630.

LIST OF EFFECTIVE PAGES

<u>Chapter</u> <u>/Page No.</u>	<u>Change No.</u>	<u>Chapter</u> <u>/Page No.</u>	<u>Change No.</u>
Title Cover	2	Chapter 5	
		5-1 thru 5-5	1
Preface		5-6	2
ii thru iii	2	5-7	1
iv thru v	1	5-8 thru 5-9	2
vi thru viii	2	5-10	1
ix	1	5-11 thru 5-12	2
x	2	5-13 thru 5-14	1
		Chapter 6	
Table of Contents		6-1	1
xi thru xiv	2	6-2	2
xv	1	6-3	1
		6-4 thru 6-6	2
Chapter 1		6-7	1
1-1 thru 1-10	2	6-8	2
		6-9 thru 6-10	1
Chapter 2		6-11	2
2-1 thru 2-2	0	6-12	1
2-3	2	6-13 thru 6-24	2
2-4 thru 2-6	0	6-25	1
		6-26	2
Chapter 3		6-27	1
3-1 thru 3-2	2	6-28 thru 6-30	2
3-3	1		
3-4 thru 3-5	2	Chapter 7	
3-6	1	7-1 thru 7-4	1
3-7 thru 3-14	2	7-5 thru 7-6	2
3-15	1	7-7/7-8	1
3-16	2		
3-17	1	Chapter 8	
3-18	2	8-1 thru 8-38	2
3-19 thru 3-20	1		
		Appendix A	
Chapter 4		A-1 thru A-12	2
4-1 thru 4-8	2		

CHANGE STATUS

Change No. 0: Original Issue: September 15, 1995.

Change No. 1: Revision A: January 15, 1997. Incorporating ECO 3313, 3458, 3459, 3499.

Change No. 2: Revision B: May 1, 2002. Incorporating ECO 16203, 16258, 16273, 16497, 16592, 16594, 16630.

LIST OF EFFECTIVE PAGES

<u>Chapter</u> <u>/Page No.</u>	<u>Change No.</u>
Appendix B	
B-1	1
B-2	2
B-3	1
B-4 thru B-5	2
B-6 thru B-8	1
Appendix C	
C-1 thru C-9	1
Appendix D	
D-1	2
Appendix E	
E-1 thru E-4	1
Appendix F	
F-1 thru F-22	2
Appendix G	
G-1 thru G-4	2
Index	
1 thru 8	2

Statements and Notices

Statement of warranty

All products of Dranetz-BMI are warranted to the original purchaser against defective material and workmanship for a period of one year from the date of delivery. Dranetz-BMI will repair or replace, at its option, all defective equipment that is returned, freight prepaid, during the warranty period. There will be no charge for repair provided there is no evidence that the equipment has been mishandled or abused. This warranty shall not apply to any defects resulting from improper or inadequate maintenance, buyer-supplied hardware/software interfacing, unauthorized modification or misuse of the equipment, operation outside of environmental specifications, or improper site preparation or maintenance.

Statement of reliability

The information in this manual has been reviewed and is believed to be entirely reliable, however, no responsibility is assumed for any inaccuracies. All material is for informational purposes only and is subject to change without prior notice.

Notice regarding FCC compliance

This device has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his/her own expense.

Notice regarding proprietary rights

This publication contains information proprietary to Dranetz-BMI. By accepting and using this manual, you agree that the information contained herein will be used solely for the purpose of operating equipment of Dranetz-BMI.

Continued on next page

Statements and Notices, Continued

Copyright	This publication is protected under the Copyright laws of the United States, Title 17 et seq. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form, by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written consent of Dranetz-BMI, 1000 New Durham Road, Edison, New Jersey 08818.
------------------	--

Copyright © 1995, 1997, 2002 Dranetz-BMI
All Rights Reserved. Printed in the United States of America.

Trademarks	Power Platform, TASKCard, and Scope Mode are registered trademarks of Dranetz-BMI.
-------------------	--

Table of Contents

Safety Summary.....	iv
Statements and Notices	ix
CHAPTER 1 - Introduction	
Overview	1-1
Unpacking The 4300.....	1-5
Physical Description	1-6
Operational Description	1-8
CHAPTER 2 - Controls, Indicators, and Connectors	
Overview	2-1
Top and Front Panels	2-2
Rear, Right, and Left Panels	2-4
Bottom Panel.....	2-6
CHAPTER 3 - Basic Operation	
Overview	3-1
Power Requirements	3-2
Installing a TASKCard	3-3
Initial Power Turn On	3-4
Common Screen Features	3-7
Connecting Voltage Measurement Cables	3-8
Connecting a Current Probe.....	3-14
CHAPTER 4 - Scope and Meter Mode	
Overview	4-1
Viewing Scope Mode.....	4-2
Viewing Meter Mode	4-4
Viewing Voltage and Current Phasors.....	4-7
Viewing Harmonics	4-8
CHAPTER 5 - Housekeeping Functions	
Overview	5-1
Entering a Site Name	5-2
Setting the Time and Date	5-4
Setting the LCD Light, Audible Alarm and Language	5-6
Clearing Memory	5-7
Resetting the 4300 to the Factory Configuration	5-8
Checking Site Status	5-11

Table of Contents, Continued

Checking 4300 Status	5-12
Running a Self-Test	5-13
CHAPTER 6 - Long-term Monitoring	
Overview	6-1
Using Easy Start.....	6-3
Turning Input Channels On and Off	6-6
Selecting Your Circuit Type	6-8
Scale Factors	6-10
Entering Scale Factors	6-11
Frequency Synchronization	6-13
Setting Sync Parameters	6-15
Changing the Timed Interval Setting	6-17
Editing Parameter Thresholds.....	6-19
Setting Waveform Capture	6-27
Activating a Setup.....	6-29
Turning Monitoring On	6-30
CHAPTER 7 - Saving Data	
Overview	7-1
Setting Memory Storage Mode	7-2
Automatically Saving Data to a Memory Card	7-3
Manually Saving Data to a Memory Card	7-5
CHAPTER 8 - Viewing Data	
Overview	8-1
Section A -Copying Memory Card Files into Internal Memory	8-3
Overview	8-3
Reading the Auto-Transfer File From a Memory Card	8-5
Reading an Event File from a Memory Card.....	8-8
Section B -Graphic Summaries	8-9
Overview	8-9
Viewing Time Plots	8-10
Selecting a Parameter.....	8-12
Using Horizontal Zoom	8-13
Changing the Vertical Scale	8-15
Viewing the Event Activity Plot	8-17
Section C -Events	8-18
Overview	8-18
Viewing the Event Report.....	8-19
Event Descriptions	8-20

Table of Contents, Continued

Viewing Worst Case Events	8-23
Viewing Event Details	8-25
IEEE 1159 Classifications	8-26
Section D -Event Waveforms	8-27
Overview	8-27
Viewing Event Waveforms.....	8-28
Analyzing Event Waveforms	8-30
Section E -Downloading Events from 4300 to a Computer	8-32
Hardware Requirements	8-33
Software Requirements	8-34
Connection Guidelines.....	8-36
Downloading Events	8-37
APPENDIX A - Optional Accessories	
Overview	A-1
Section A -Optional Accessories	A-2
Overview	A-2
Optional Accessories List	A-3
Optional Accessories Descriptions	A-5
Section B -CompactFlash Card.....	A-9
Overview	A-9
CompactFlash Card Power Features	A-10
Using CompactFlash Card with the PP4300.....	A-11
Using CompactFlash Card with TASKCard PQLite V4.2 or higher	A-12
APPENDIX B - Technical Specifications	
Overview	B-1
General	B-2
Interfaces.....	B-3
Measured Parameters.....	B-4
Computed Parameters	B-6
TR2500 Current Probe	B-8
APPENDIX C - Battery Specifications and Replacement Procedure	
Overview	C-1
Battery Specifications	C-2
Battery Pack Safety Precautions	C-3
Battery Pack Replacement	C-5
Memory Card Battery Replacement	C-7
APPENDIX D - Operator Replaceable Parts List	

Table of Contents, Continued

APPENDIX E - System Messages

Overview	E-1
Message Types.....	E-2
Messages	E-3


APPENDIX F - Common Circuit Connections

Overview	F-1
Verifying Voltage and Current Connections	F-5
Single Phase	F-8
Split Phase	F-9
Four Wire Wye	F-10
Floating or Grounded Delta	F-11
Open Leg Delta.....	F-13
High-Leg Delta	F-14
Connecting to a Potential Transformer (PT).....	F-15
Connecting to a Current Transformer (CT)	F-17
Connecting to an Isolated Current Transformer (ISO)	F-19

APPENDIX G - PQLite Menu Structure

Overview	G-1
Scope/Meter Mode Menu	G-2
View Data Menu	G-3
Setup Menu	G-4

INDEX



4300-16

Dranetz Power Platform, Model 4300

Chapter 1

Introduction

Overview



4300 description	<p>The Dranetz Power Platform® Model 4300 is a portable, hand-held, TASKCard® based, eight-channel power quality meter/monitor. The 4300 can monitor, record and display data on four voltage channels and four current channels simultaneously. Data can be recorded and transferred to a personal or laptop computer using the Isolated Communications Module (P/N PP4300 RS232) and the DRAN-LINK™ 4300 utility software. The DRAN-LINK™ 4300 can download data from the unit's internal memory or from an optional memory card. With TASKCard® PQLite V4.0 or higher, the 4300 can handle multi-lingual display of text and help screens. The help files are programmed for context sensitivity, displaying the appropriate help topics on specific errors committed. Context sensitive help is available in English, French, Italian, German and Spanish languages.</p>
TASKCard definition	<p>A TASKCard is a removable program card that is inserted in the 4300. It contains an operating system designed for a specific application (task).</p> <p>Latest TASKCard® PQLite releases include V4.0 and V4.2.</p> <ul style="list-style-type: none">• TASKCard® PQLite V4.0 or higher offer upgrade features like Language Selection and Scope Mode Timeout. See below for details on Language Selection and see page 4-2 for details on Scope Mode timeout.• TASKCard® PQLite V4.2 or higher support the use of CompactFlash memory cards. CompactFlash is the new, performance versatile card replacing the old type of SRAM memory (data) cards. See page 1-10 for details.
Language Selection	<p>TASKCard® PQLite V4.0 or higher support features such as Language Selection. Users now have the option to navigate the 4300 menu screens in any of the following languages:</p> <ul style="list-style-type: none">• English• French• Italian• German• Spanish <p>To select another language, see instructions on page 1-2.</p>

Continued on next page

Overview, Continued

Language Selection (continued)

Follow these steps to select a new language.

Step	Action
1	At start up, press SETUP from the SCOPE MODE screen.
2	<p>From the SETUP menu, select item 2, SET PROGRAMMABLE FEATURES.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="683 621 1289 957"></div> <p>4300B-101</p>
3	<p>Select item 5, SELECT LANGUAGE.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="677 1140 1289 1467"></div> <p>4300B-102</p>
4	Press NEXT LANG until the desired language appears on the screen.
5	Press SELECT to choose the Present Language.
6	<p>Press EXIT to enable the language selected.</p> <p><u>Result:</u> All screens will be displayed in the selected language.</p>

Overview, Continued

PQLite TASKCards available

The PQLite TASKCard is available in two model configurations:

PQLite HTEM 1 Phase (Single Phase)

The Single Phase PQLite TASKCard turns the 4300 into a power quality monitor that records sags, swells, interruptions, transients, and power. It provides full power quality and harmonics monitoring for two (2) active channels (V/I) and neutral (V/I). From the four A, B, C and D Channel connectors found in the 4300 instrument, only Channels A and D are valid and enabled when using Single Phase TASKCards. Channels B and C are masked and set to OFF by default. The Single Phase TASKCard can measure, record and analyze up to sixteen (16) power quality parameters. It has memory card functions that allow data to be saved to an optional memory card manually, automatically, or both. The DRANETZ-BMI TASKCard® system allows users to easily and cost-effectively upgrade the 4300 instrument by simply switching from a Single Phase to a Three Phase TASKCard.

PQLite HTEM 3 Phase (Three Phase)

The Three Phase PQLite TASKCard turns the 4300 into a power quality monitor that records sags, swells, interruptions, power, harmonics and transients. It incorporates all previous individual TASKCard PQLite/H-T-M (harmonics, transient capture, memory) functionalities, plus demand and energy recording. The Three Phase TASKCard provides for eight (8) channel monitoring (4V/4I) of power quality, harmonics and energy. All four A, B, C and D Channel connectors are valid and enabled when using Three Phase TASKCards. It also has memory card functions, which allow data to be saved to an optional memory card manually, automatically, or both.

PQLite TASKCard



Continued on next page

Overview, Continued

This manual This manual contains instructions for operating the Dranetz 4300 with any kind of PQLite TASKCard installed. Functions that are specific to each kind of TASKCard will be noted as such where they are discussed.

Specifically, functions specific to a Single Phase TASKCard are accompanied by the heading ! FOR SINGLE PHASE TASKCARD.

Where there is no reference made to a particular TASKCard, this means that the functionalities apply to both Single Phase and Three Phase TASKCards.

In this chapter The following topics are covered in this chapter.

Topic	See Page
Unpacking the 4300	1-3
Physical Description	1-6
Operational Description	1-8

Unpacking The 4300

Introduction For maximum protection against possible shipping damage, the 4300 has been sealed in a two-piece, plastic suspension pack, enclosed within a durable shipping carton. After opening the carton, inspect the contents for possible shipping damage and check the carton inventory.

Unpacking Unpack the 4300 from the carton as follows:

Step	Action
1	Remove any remaining literature inside the top of the carton.
2	Carefully remove the 4300 from its shipping carton.
3	Remove all accessories inside the carton. Check that all of the standard accessories (See next page) are included.

Shipping damage inspection Visually inspect the 4300 for possible shipping damage. If any damage exists, first notify and file an insurance claim with your carrier or underwriter or both. Then notify Dranetz Customer Service Department of your intentions to return the unit. DO NOT return the 4300 without prior instructions from Dranetz Customer Service Department. Dranetz Customer Service Department can be reached at (732) 287-3680 or 1-800-DRANTEC.

Repacking for return shipment If the unit must be returned to Dranetz for service or repair, wrap the unit securely in heavy packaging material and place in a well padded box or crate to prevent damage. Do not return the 4300 in an unpacked box. Dranetz Technologies Inc. will not be responsible for damage incurred during transit due to inadequate packing on your part.

Return notice Notify Dranetz Customer Service of your intention of returning the unit. Do not return the unit without prior instructions from Dranetz. Dranetz Customer Service Department can be reached at (732) 287-3680 or 1-800-DRANTEC.

Physical Description

Dimensions The Dranetz 4300 is a self-contained, portable instrument weighing less than 5 pounds and measuring 8" (20.3 cm) deep by 12" (30.5 cm) wide by 2.5" (6.4 cm) high.

Top and front panels The top panel contains the screen and keypad. The front panel contains two slots for holding a TASKCard and a memory card. See Chapter 2 for descriptions of the top and front panel controls and indicators, and connectors.

Rear and side panels The rear panel contains the input voltage and current connectors. The left and right side panels contain the optical interface port and ac adapter input connector, respectively and rings for attaching the supplied carrying strap. See Chapter 2 for descriptions of the rear and side panel connectors.

Standard accessories The following table lists the 4300's standard accessories.

Description	Part Number
AC Adapter/Battery Charger	116297-G1
Cable Pouch	116043-G1
Carrying Strap	116040-G1
Easel	116038-G1
Operator's Manual	OM-4300-PQLITE
*Power Cord, Shielded, 125V 10A	110727-G3
*Power Cord, Shielded, 230 Vac (Euro)	115369-G1
*Power Cord, Shielded, 230 Vac (UK)	115368-G2
*PQLite HTEM Single Phase TASKCard and Memory Card Functions	PQLITE HTEM/1PHASE
*PQLite HTEM Three Phase TASKCard and Memory Card Functions	PQLITE HTEM/3PHASE
Quick Reference Guide	899021
Voltage Cable Assembly, 4 Pair w/Alligator Probes	116042-G1
*Voltage Cable Accessory	116264-G1
*User specified, one standard only.	

Physical Description, Continued

Optional accessories

The optional accessories are described in Appendix A.

Replaceable parts

Refer to Appendix D for operator replaceable parts.

Batteries

Refer to Appendix C for the description and replacement of the batteries contained in the 4300.

Calibration

The recommended calibration interval for this unit is once every 12 months.

We recommend that you return the unit to the factory for calibration. If you decide to do so, first contact the Dranetz Customer Service Department to obtain an Authorization Number.

Telephone: (732) 287-3680 or 1-800-DRANTEC
FAX: (732) 248-9240

Fill out the Repair/Service Order form enclosed in the shipping carton and ship it along with the unit to the Dranetz Repair Department. (If this form is missing, ask the Dranetz Customer Service Department for a replacement.)

Operational Description

Scope Mode	<p>The 4300 powers up in Scope Mode®. Scope Mode functions as an oscilloscope, displaying real-time waveforms of voltage and current for all channels.</p>
Meter mode	<p>Meter mode provides the functions of a true RMS voltmeter and true RMS clamp-on ammeter. Voltage and current measurements, along with all other calculated parameters, are displayed on the Meter Mode screens.</p> <p>The 4300 can also display voltage and current phasors for all of the channels. Functioning as a phase angle meter, the 4300 can display system imbalance conditions. The phase angle display can also verify that monitoring connections have been made correctly.</p>
Monitoring capacity	<p>The Dranetz 4300 can monitor any of the following power configurations:</p> <ul style="list-style-type: none">• Single phase, 2 wire• Split phase, 3 wire• 3 phase, 3 wire (delta)• 3 phase, 4 wire (wye) <p>While monitoring any of the above configurations (except delta), the 4300 can also be connected to monitor neutral to ground voltage and neutral or ground current.</p>
Technical specifications	<p>Specifications for the 4300, measured parameters, computed parameters, current probes, and isolated current transformers, are listed in Appendix B.</p>
Easy Start	<p>The Easy Start function prompts you for information about the circuit you want to monitor and then automatically sets up the 4300 for monitoring. For complete information about operating Easy Start, see Chapter 6.</p>
Setup	<p>The setup is a list of parameter thresholds that control the data recorded by the 4300.</p>


Continued on next page

Operational Description, Continued

Events	An event is data that is stored in memory when a programmed threshold is crossed (either going out-of-limits or on return-to-normal), when a device is configured, or when system status changes.
<hr/>	
Help	Help is available by pressing the question mark (?) key on the numeric keypad. A help screen is a one page description of the screen (function) presently displayed.
<hr/>	
Menu structure	Refer to Appendix G for the menu structure of the PQLite TASKCard.
<hr/>	
Memory Card (old model)	A memory (data) card is used with the 4300 to provide a removable, rugged, compact, solid state mass storage device. A memory card, shown below, uses low power, has an internal battery for data retention, and is available as an optional accessory in sizes from 2MB to 4 MB.

For information about changing the battery, refer to Appendix C.

The old model memory card is now replaced by the more sleek and versatile CompactFlash Card described on page 1-10.



4300B-04

Continued on next page

Operational Description, Continued

CompactFlash Memory Card (new model)

TASKCard® PQLite V4.2 or higher support the use of CompactFlash cards - a vastly improved replacement for old model memory cards that is now available for use with the PP4300.

The CompactFlash card has a more robust data handling and storage capability, and is available in sizes ranging from 8MB to 32MB. It can format and create data files in seconds. The card can accommodate up to 8 MB of auto-transfer files. Multiple auto-transfer files are possible in one card. CompactFlash is available to consumers at lower cost.

For information on how to use the CompactFlash card with PP4300 and TASKCard® PQLite V4.2, refer to Appendix A - Section B on page A-9.

Chapter 2

Controls, Indicators, and Connectors

Overview


Introduction This chapter identifies and describes the controls, indicators, and connectors on all panels of the 4300.

In this chapter The following topics are covered in this chapter.

Topic	See Page
Top and Front Panels	2-2
Rear, Right, and Left Panels	2-4
Bottom Panel	2-6

Top and Front Panels




Diagram



Continued on next page


Top and Front Panels, Continued

Parts Table

Part	Function
1	Liquid Crystal Display (LCD). Provides 2-3/4 x 4-1/2 inches (5 x 10 cm) display consisting of 240 by 128 pixels (dots) of text and graphic information. Has electroluminescent (EL) backlighting for low light level viewing.
2	Numeric keypad. Consists of keyboard keys 0 thru 9 and decimal point (.). Permits menu selection and numerical data entry.
3	Question Mark Key. Displays help screen with reference to screen displayed at any time.
4	LCD Contrast Adjustment Key. Symbol:  . Press and hold for continuous contrast range change, release to stop. Press and quickly release for incremental contrast change.
5	Battery Charge Indicator. LED is on continuously while battery is fast charging and blinking when fully charged. Symbol: 
6	On/Off Power Key. Symbol:  . Push for on, push for off.
7	Data Card Holder. Holds and connects memory (data) card to internal circuitry.
8	Data Card Release. Ejects memory (data) card.
9	TASKCard Release. Ejects TASKCard.
10	TASKCard, connector slot.
11	Function Keys. Six keys used to select options that appear on bottom of screen. Function selected varies with screen displayed.

Rear, Right, and Left Panels

Diagram



4300-18


Continued on next page

Rear, Right, and Left Panels, Continued

Parts Table

Part	Description
1	CH A, + Differential Voltage Input Connector; color red.
2	CH A, - Differential Voltage Input Connector; color white.
3	CH A, PROBE, Current Input Connector.
4	CH B, + Differential Voltage Input Connector; color yellow.
5	CH B, - Differential Voltage Input Connector; color white.
6	CH B, PROBE, Current Input Connector.
7	CH C, + Differential Voltage Input Connector; color blue.
8	CH C, - Differential Voltage Input Connector; color white.
9	CH C, PROBE, Current Input Connector.
10	CH D, + Differential Voltage Input Connector; color grey.
11	CH D, - Differential Voltage Input Connector; color white.
12	CH D, PROBE, Current Input Connector.
13	AC Adapter/Battery Charger Input Connector.
14	Optical Serial Data Port.

Bottom Panel



4300-24

Chapter 3

Basic Operation

Overview

In this chapter The following topics are covered in this chapter.

Topic	See Page
Power Requirements	3-2
Installing a TASKCard	3-3
Initial Power Turn On	3-4
Common Screen Features	3-7
Connecting Voltage Measurement Cables	3-8
Connecting a Current Probe	3-14

Power Requirements

Introduction	<p>The normal power source for the 4300 is its internal battery pack. The AC Adapter/Battery Charger is used to charge the battery. Always charge the battery fully before use. The 4300 will always operate on the charger and is designed to do so, regardless of the state of charge of the battery.</p>
Battery pack	<p><u>Length of operation:</u> The 4300 can operate on a fully charged battery pack for up to four hours. A screen warning will appear during operation when battery charge is low.</p> <p><u>Charging:</u> The battery pack can be charged by connecting the AC Adapter/Battery Charger to the 4300. A depleted battery pack can be recharged in two hours with the unit off and twenty-four hours with the unit on. The Battery Charge Indicator glows steadily while charging, and flashes when fully charged.</p> <p>NOTE: The Battery Charge Indicator functions only when the unit is turned OFF and the AC Adapter/Battery Charger is properly connected.</p>
AC power source	<p>The 4300 can be operated from a 50/60 Hz ac power source with or without the battery pack installed.</p> <p>Connect the AC Adapter output cable to the Input Connector on the right side of the PP4300. Connect the AC Adapter power cord to an appropriate outlet.</p> <p>WARNING: Refer to the next sections Connecting Voltage Measurement Cables and Connecting a Current Probe, and refer to Appendix F Common Circuit Connections, for detailed descriptions of common power monitoring configurations and cable connections.</p>

Installing a TASKCard

Procedure



Follow these steps to install a TASKCard.

Step	Action
1	Press 4300 On/Off power key to turn unit off.
2	Remove TASKCard from its protective holder and check that the plug end of card is clean and free of any obstruction. NOTE: If plug end of card is dirty, clean with static-free, dry, low pressure air to remove any foreign material causing obstruction of the plug holes.
3	Verify that the write protect switch (end opposite plug) is set to the write protect position. Use pencil point to move switch.
4	At the rear of the unit, position the TASKCard with the label facing up and the plug end facing the TASKCard slot.
5	Insert the card fully into the slot until resistance is felt, then press firmly until the card engagement is felt. NOTE: Do not force the card further into the slot if no card engagement is felt. Remove card and check if there is foreign object on or in the plug end of the card. Remove any obstruction. Reinsert card and repeat card engagement. If card cannot be engaged, STOP all further action and call Dranetz Service for assistance.
6	Go to next page for power turn on procedure.

Initial Power Turn On

NOTE For the initial power turn on do not connect any voltage or current probes.

Power on sequence

Step	Action
1	Connect ac adapter/battery charger plug into right side of 4300.
2	Plug the ac adapter plug into an ac power source.
3	<p>Press the 4300 On/Off power key to on.</p> <p><u>Result:</u> The following sequence of screens will be displayed during a successful power turn on using a Three Phase TASKCard.</p> <div><div><p>If any test reads "Failed", restart the unit. If failure persists, call Dranetz at 1-800-DRANTEC.</p></div><p>↓</p><div><p>If an error message is displayed, refer to "TASKCard error messages" on page 3-6.</p><p>A sync status message will appear briefly.</p></div></div>



To display the Scope Mode screen, select NO at the Select Current Probe(s) prompt.

Continued on next page

Initial Power Turn On, Continued

Power on
sequence

! FOR SINGLE PHASE TASKCARD

Step	Action
1	Connect ac adapter/battery charger plug into right side of 4300.
2	Plug the ac adapter plug into an ac power source.
3	<p>Press the 4300 On/Off power key to on.</p> <p><u>Result:</u> The following sequence of screens will be displayed during a successful power turn on using a Single Phase TASKCard.</p> <div><div><p>4300Ba-302</p></div><div><p>If any test reads "Failed", restart the unit. If failure persists, call Dranetz at 1-800-DRANTEC.</p></div></div> <p style="text-align: center;">↓</p> <div><div><p>4300-35</p></div><div><p>If an error message is displayed, refer to "TASKCard error messages" on page 3-6.</p><p>A sync status message will appear briefly.</p></div></div>

To display the Scope Mode screen, select NO at the Select Current Probe(s) prompt.

Continued on next page

Initial Power Turn On, Continued

TASKCard error messages

The following table describes the possible error messages when loading the TASKCard and the corrective action to take for each.

NOTE

If no error messages are displayed, proceed to the next page.


Error Message	What to do Next
TASKCard Not Found. Please turn off instrument and insert valid model 4300 card.	TASKCard may not be installed or is installed incorrectly. Turn off power and recheck TASKCard installation.
Invalid TASKCard. Please turn off instrument and insert valid model 4300 card.	A TASKCard was found but it was not recognized as a valid TASKCard. Turn off power and recheck TASKCard. If the TASKCard is properly inserted, there may be a problem. Call Dranetz for further assistance.
WARNING: The Task Card found: (now installed) Is different than last used: (previous Task Card) CHANGING TASK CARDS MAY ERASE MEMORY!	Press any key to continue or turn off the unit and reinstall the last TASKCard used.
Any of the following: <ul style="list-style-type: none">•DSP Processor Download Failed•DSP Processor Will Not Respond	TASKCard download problem. Call Dranetz Technical Support at 1-800-DRANTEC for further assistance.

Common Screen Features

Introduction

The Scope Mode screen, shown below, is the main screen of the 4300 using a Three Phase TASKCard. The Scope Mode screen in Single Phase TASKCards display exactly the same features except that it offers Channel connectors A and D only. This screen is frequently referenced as the starting point in both Single Phase and Three Phase TASKCards. Common screen features are shown below.

Scope Mode screen



Description of common features

Date and time: The date and time will appear at the top of each screen.

Messages: System information and error conditions appear at the top of the screen between the date and time. Refer to Appendix E for a complete list.

Display area: The display area changes with each screen, displaying menus, metering functions, setup information and data.

Menu bar: The menu bar changes with each screen and provides up to six function keys. Most screens have keys that operate only on that screen, such as the SELECT CHAN and SAVE keys shown above. Other keys provide access to other functions such as METER MODE, HARMONICS, VIEW DATA, and SETUP.

Returning to Setup menu

To return to the SETUP menu from any screen, press the EXIT key repeatedly.

Connecting Voltage Measurement Cables

Introduction This section describes how to connect the 4300 to make basic single phase voltage measurements. For multi-phase connection diagrams, refer to Appendix F.

WARNING **Death, serious injury, or fire hazard could result from improper connection of this instrument. Read and understand this manual before connecting this instrument. Follow all installation and operating instructions while using this instrument.**

Connection of this instrument must be performed in compliance with the National Electrical Code (ANSI/NFPA 70-2002) and any additional safety requirements applicable to your installation.

Installation, operation, and maintenance of this instrument must be performed by qualified personnel only. The National Electrical Code defines a qualified person as “one who has the skills and knowledge related to the construction and operation of the electrical equipment and installations, and who has received safety training on the hazards involved.”

Qualified personnel who work on or near exposed energized electrical conductors must follow applicable safety related work practices and procedures including appropriate personal protective equipment in compliance with the Standard for Electrical Safety Requirements for Employee Workplaces (ANSI/NFPA 70E-2000) of USA and any additional workplace safety requirements applicable to your installation.

ADVERTENCIA Una conexión incorrecta de este instrumento puede producir la muerte, lesiones graves y riesgo de incendio. Lea y entienda este manual antes de conectar. Observe todas las instrucciones de instalación y operación durante el uso de este instrumento.

La conexión de este instrumento debe ser hecha de acuerdo con las normas del Código Eléctrico Nacional (ANSI/NFPA 70-2002) de EE. UU., además de cualquier otra norma de seguridad correspondiente a su establecimiento.

La instalación, operación y mantenimiento de este instrumento debe ser realizada por personal calificado solamente. El Código Eléctrico Nacional define a una persona calificada como "una que esté familiarizada con la construcción y operación del equipo y con los riesgos involucrados."

Continued on next page

Connecting Voltage Measurement Cables, Continued

AVERTISSE- MENT

Si l'instrument est mal connecté, la mort, des blessures graves, ou un danger d'incendie peuvent s'en suivre. Lisez attentivement ce manuel avant de connecter l'instrument. Lorsque vous utilisez l'instrument, suivez toutes les instructions d'installation et de service.

Cet instrument doit être connecté conformément au National Electrical Code (ANSI/NFPA 70-2002) des Etats-Unis et à toutes les exigences de sécurité applicables à votre installation.

Cet instrument doit être installé, utilisé et entretenu uniquement par un personnel qualifié. Selon le National Electrical Code, une personne est qualifiée si "elle connaît bien la construction et l'utilisation de l'équipement, ainsi que les dangers que cela implique."

WARNUNG

Der falsche Anschluß dieses Gerätes kann Tod, schwere Verletzungen oder Feuer verursachen. Bevor Sie dieses Instrument anschließen, müssen Sie die Anleitung lesen und verstanden haben. Bei der Verwendung dieses Instruments müssen alle Installation- und Betriebsanweisungen beachtet werden.

Der Anschluß dieses Instruments muß in Übereinstimmung mit den nationalen Bestimmungen für Elektrizität (ANSI/NFPA 70-2002) der Vereinigten Staaten, sowie allen weiteren, in Ihrem Fall anwendbaren Sicherheitsbestimmungen, vorgenommen werden.

Installation, Betrieb und Wartung dieses Instruments dürfen nur von Fachpersonal durchgeführt werden. In den nationalen Bestimmungen für Elektrizität wird ein Fachmann als eine Person bezeichnet, welche "mit der Bauweise und dem Betrieb des Gerätes sowie den dazugehörigen Gefahren vertraut ist."

Continued on next page

Connecting Voltage Measurement Cables, Continued

WARNING	To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.
WARNING	To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse the voltage measurement inputs. Fuses must be located as close to the load as possible to maximize protection.
WARNING	For continued protection against risk of fire or shock hazard replace only with same type and rating of recommended fuse. Use only fast blow type fuse which is rated 600V. Recommended fuse type is Littelfuse, part number KLKD0.25 rated 600V AC/DC, 0.25 A fast blow.
WARNING	Do not replace fuse again if failure is repeated. Repeated failure indicates a defective condition that will not clear with replacement of the fuse. Refer condition to a qualified technician.
Safety precautions	<p>The following safety precautions must be followed whenever any type of voltage or current connection is being made to the 4300.</p> <ul style="list-style-type: none">• Wear proper Personal Protective Equipment, including safety glasses and insulated gloves when making connections to power circuits.• Hands, shoes and floor must be dry when making any connection to a power line.• Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.• Press the 4300 On/Off power key to Off.• Before connecting to electric circuits to be monitored, open their related circuit breakers or disconnects. DO NOT install any connection of the 4300 to live power lines.• Connections must be made to the 4300 first, then connect to the circuit to be monitored.

Continued on next page

Connecting Voltage Measurement Cables, Continued

Measurement cable set


Description: Voltage measurement cables are provided as standard accessories and are stored in a cable pouch as part of the measurement cable set, part number 116042-G1. Each cable set consists of a cable and alligator clip.

Voltage Rating: Direct connection of all voltage measurement cables are rated at 600 Vrms max. For measuring voltages greater than 600 Vrms, potential transformers (PTs) must be used.

Contents: The voltage measurement cables are shown on the next page (positioned relative to their actual use). A cable set consists of eight, 6-foot channel measurement cable assemblies (probes), each with a detachable, alligator jaw, safety clip assembly (maximum jaw opening, 3/4 in (20 mm)). The safety clip assemblies are red (+) and black (-) for each of the four channels. One cable each of red (channel A), yellow (channel B), blue (channel C), and gray (channel D), and four each of white are provided.

A pouch for storage of the cables and the AC adapter/battery charger is included in the contents of the measurement cable set, but is not shown in the figure.

Measurement cable set diagram



Continued on next page

Connecting Voltage Measurement Cables, Continued


Connection guidelines

Follow these guidelines when making voltage connections.

- Refer to the measurement cable set figure for color coding of probes that connect to input channel connectors A, B, C, and D.
- Each channel input has plus (+) and minus (-) differential inputs of 60 to 600 Vrms max.
- Channel D has an additional low voltage range of 0.5 to 20 Vrms max. for low voltage measurements.

Example: Single phase connection

The following figure shows a voltage connection to a single phase circuit for channel A.




4300-20

Continued on next page

Connecting Voltage Measurement Cables, Continued

Example: Neutral to ground connection

The following figure shows a voltage connection using channel D as a differential input for measuring neutral to ground voltage. Connections are identical for split phase, high-leg delta, and wye configurations. One probe connects the source neutral line to the D+ input. Another probe connects the ground to the D- input. Any channel input may be used to perform this measurement but Channel D is usually used because it provides a low voltage range of 0.5 to 20 Vrms.



4300-21

Connecting a Current Probe

Safety precautions

The following safety precautions apply to current probe connections in addition to those safety precautions stated on page 3-10.

- DO NOT attempt to measure current in any circuit in which the circuit to ground voltage exceeds the insulation rating of the current probe (600 Vrms max).
- Make sure the jaws of the current probe are tightly closed. Keep mating surfaces clean and free from foreign matter.

WARNING

When using the TR2021, TR2021A or TR2510 current probe, DO NOT clamp the probe jaws around a non-insulated wire. These probes are designed for use around insulated wire only.

ADVERTENCIA

Cuando utilice sondas de corriente TR2021, TR2021A o TR2510 NO sujete las mordazas de la sonda alrededor de un alambre sin aislamiento. Estas sondas están diseñadas para usarse alrededor de cables aislados únicamente.

AVERTISSEMENT

Lorsque vous utilisez la sonde de courant TR2021, TR2021A ou TR2510, NE CLAMPEZ PAS les mâchoires de la sonde autour d'un fil non isolé. Ces sondes sont conçues pour emploi exclusif autour de fils isolés.

WARNUNG

Bei der Verwendung der Stromsonde TR2021, TR2021A oder TR2510 die Sondenbacken NICHT um einen nicht isolierten Draht klemmen. Diese Sonden sind nur für den Einsatz um isolierten Draht vorgesehen.

Current probes

Several Dranetz current probes can be used with the 4300. Typical current probes are illustrated on the following page. Refer to Appendix A for descriptions and part numbers for probes and adapter cables. Refer to Appendix B for specifications for model TR2500.

NOTE: The TR2500 can perform all current measurements except transient detection.

Continued on next page

Connecting a Current Probe, Continued

**Current probes
(continued)**

Probe positioning: An arrow marking on the handle is a guide to ensure that you position the probe with the arrow pointing towards the load when monitoring the line conductor. Correct position of the probe is necessary for correct power measurements, where in-phase voltage and current measurements are necessary. A positive watts reading indicates that the probe is pointed towards the load, and a negative reading indicates that the probe is pointed towards the source.


**Reference to
channel input**

Because no reference at the probe end identifies which channel is being monitored, a wire marker kit is supplied as a standard accessory to help in probe/channel identification. This kit, part number 155520, provides color-coded channel marker labels to attach to both the probe handle and the plug end of the probe.

Continued on next page

Connecting a Current Probe, Continued

Typical current probes



Continued on next page

Connecting a Current Probe, Continued


Connection guidelines

Follow these guidelines when making current connections.


- Position the probe with the arrow on the handle pointing towards the load.
- For greatest accuracy, use a probe that is rated at no more than twice the nominal value you expect to measure.

Connecting a probe before turning the 4300 on

The following default screen appears during the start up sequence using a Three Phase TASKCard. It appears when the unit is turned on, whether a current probe is connected or not.



Selecting NO will cause the Scope Mode screen to appear, shown on page 3-7. Selecting YES will cause the Current Probe Selection screen to appear, shown below.



Current Probe Selection Screen


Continued on next page

Connecting a Current Probe, Continued

! FOR SINGLE PHASE TASKCARD

Connecting a probe before turning the 4300 on


The following default screen appears during the start up sequence using a Single Phase TASKCard. It appears when the unit is turned on, whether a current probe is connected or not.



4300B-303

Selecting NO will cause the Scope Mode screen to appear, shown on page 3-7. Selecting YES will cause the Current Probe Selection screen to appear, shown below.

The screen allows you to select the probe you are using for channels A and D.



The screen defaults to the last selected probes.

Press EXIT to return to the previously displayed screen.

4300B-304

—Cycles through the available probes.

—Moves the highlight to the next channel.

Current Probe Selection Screen

Continued on next page

Connecting a Current Probe, Continued

Connecting a probe after turning the 4300 on

To change probes while the 4300 is turned on, follow these steps to return to the Current Probe Selection screen.

Step	Action
1	From the Scope Mode screen or View Data menu, press the SETUP key.
2	From the SETUP menu, select “5. Advanced Setup Options.”
3	From the Advanced Setup Options menu, select “1. Set Input Configurations.”
4	From the Set Input Configurations menu, select “6. Set Current Probes.” <u>Result:</u> The Current Probe Selection screen will appear, as shown on the previous page.


Continued on next page

Connecting a Current Probe, Continued

Single phase current probe connection example

The following figure shows how to connect a current probe to channel A for current monitoring of a single phase line.

The current probe may be connected to the return line if desired to measure the return current when checking for load current leakage, loop current relationships, etc. If measuring power, position the probe with the arrow pointing towards the load.



4300-22

NOTE

The connection shown above is not recommended without a voltage connection to ensure frequency synchronization. If this configuration is used, then an internal frequency reference must be entered. Refer to page 6-15.

Chapter 4

Scope and Meter Mode

Overview

Introduction This chapter describes the operation of scope and meter modes, which allow you to view real-time voltage and current waveforms; values for 16 parameters; voltage and current phasors; and harmonics displays for up to the 50th harmonic.


In this chapter The following topics are covered in this chapter.

Topic	See Page
Viewing Scope Mode	4-2
Viewing Meter Mode	4-4
Viewing Voltage and Current Phasors	4-7
Viewing Harmonics	4-8

Viewing Scope Mode

Introduction Scope Mode allows you to view the real-time voltage and current waveforms for up to eight channels.

Displaying the screen The Scope Mode screen can be displayed by pressing the SCOPE MODE key on the View Data menu or the Setup menu.



Viewing Scope Mode, Continued

**Scope Mode
timeout**


The Scope Mode screen will automatically time out and return to the main menu after 15 minutes of no user activity. The display timeout reduces the possibility of Scope Mode-induced problems and ensures proper energy monitoring.

USERS ARE ADVISED NOT TO LEAVE THE UNIT IN SCOPE MODE WHILE MONITORING IS ON. Prolonged Scope Mode screen display causes problems because it grabs and holds data resource and uses a huge amount of processor time. While in Scope Mode, the instrument may not capture and accumulate energy settings accurately. Scope Mode is designed to provide real-time information on voltage and current waveforms; it is not designed to monitor events.

Viewing Meter Mode

Types of display The 4300 has four meter screens: the first three display real-time values for sixteen parameters and the fourth displays phasors. The first three screens contain the same information but in different formats.

Displaying the screen The Meter Mode screen can be displayed by pressing the METER MODE key on the Scope Mode screen, View Data menu, or Setup menu. The screens below appear when using a Three Phase TASKCard.




Continued on next page

Viewing Meter Mode, Continued

! FOR SINGLE PHASE TASKCARD

Displaying the screen

The same procedures apply to display the Meter Mode screen. Press the METER MODE key on the Scope Mode screen, View Data menu, or Setup menu. Certain channels and parameters differ according to the monitoring functions inherent in Single Phase TASKCards.



Continued on next page

Viewing Meter Mode, Continued

Available parameters

The following table lists the parameters that can be viewed in meter mode.

Parameter	Abbreviation	Screen
Volts RMS	V	1
Amps RMS	I	1
Watts	W	1
Volt-amps	VA	1
Volt-amps Reactive	VAR	2
Power Factor (True)	PF	2
Voltage Frequency	Hz	2
Voltage Unbalance	Vunb%	2
Volts, Total Harmonic Distortion	Vthd	3
Amps, Total Harmonic Distortion	Ithd	3
Current Crest Factor	Icf	3
k-Factor	KF	3
Demand	Dmd	4
Energy	WHR	4
Volts, Harmonic Number*	V harm n	4
Amps, Harmonic Number*	I harm n	4
*The harmonic number is entered on the threshold configuration screen. See Chapter 6, Editing Parameter Thresholds.		

NOTE: Meter mode operation does not interfere with any of the 4300's other monitoring or recording functions. Also, individual voltage and current channel meter readings are not affected by the monitoring setup. Turning monitoring or individual channels off does not affect meter readings.



Viewing Voltage and Current Phasors

Introduction

The phasor screens displays the voltage or current phase angles between channels or between voltage and current for a single channel. This allows you to visually check circuit connections.

Displaying the screen

The phasor screen is displayed by pressing the NEXT METER key on the Meter Mode screen.




Moves highlight to next channel.
! FOR SINGLE PHASE TASKCARD
- NEXT CHAN will automatically select only between Channels A or D

Saves all meter, phasor, and harmonic values to memory

Viewing Harmonics

Displaying the graph screen

To display the harmonics graph, press the HARMONICS key on the Scope Mode screen, the View Data menu, or the Setup menu.



Continued on next page

Viewing Harmonics, Continued

Viewing the text display To view the harmonics text display, press the TEXT MODE key from the graph display.

The display is updated every 5 seconds

Jun-20-9510:53:24

HARMONICS=CH A REF 112.8 U, 60.0Hz

%FUND Uthd

H#	MAG%	PHS	H#	MAG%	PHS	H#	MAG%	PHS
02	0.000	000	09	0.288	000	16	0.000	000
03	0.288	180	10	0.000	000	17	0.000	000
04	0.000	000	11	0.000	000	18	0.000	000
05	0.672	000	12	0.000	000	19	0.000	000
06	0.000	000	13	0.000	000	20	0.000	000
07	0.000	000	14	0.000	000	21	0.000	000
08	0.000	000	15	0.000	000	22	0.000	000

NEXT CHAN

NEXT PARAM

NEXT SET

GRAPH MODE

SAVE

EXIT

4300-50

Displays next set of values for 50/60 Hz circuits: H23-H43, H44-H50

See previous page

Saves all meter, phasor, and harmonic values to memory

NOTE: The watts parameter version of this screen indicates harmonic power direction by the sign in front of the MAG% value. A minus sign (-) indicates that the harmonic power flows from the load to the source. No sign indicates that the harmonic power flows from the source to the load.

Chapter 5

Housekeeping Functions

Overview

Introduction Housekeeping functions consists of the miscellaneous tasks that you need to perform to keep your 4300 running in an efficient and organized way. These are tasks that you might perform only occasionally.

NOTE No circuit connections need to be made for any of the procedures described in this chapter.

In this chapter The following topics are covered in this chapter.

Topic	See Page
Entering a Site Name	5-2
Setting the Time and Date	5-4
Setting the LCD Light, Audible Alarm and Language	5-6
Clearing Memory	5-7
Resetting the 4300 to the Factory Configuration	5-8
Checking Site Status	5-11
Checking 4300 Status	5-12
Running a Self-Test	5-13

Entering a Site Name

Introduction

This function allows you to enter a site name of up to 20 characters. The site name is used to create filenames on the memory card. The filenames that are created are in standard DOS format (eight characters maximum).


NOTE

You must make sure that the first eight characters for each site name are unique, otherwise, you will create files with the same name.

For example: If you name one site *4300 SITE 1*, and another *4300 SITE 2*, the filename *4300SITE* will be created for both (spaces are deleted when the filename is created).

Procedure

Follow these steps to enter a site name.


Step	Action
1	From Scope Mode, press SETUP.
2	From the Setup Menu, select item 2, Set Programmable Features.
3	From the Set Programmable Features Menu, select item 2, Set Site/File Name. <u>Result:</u> The following screen will appear. 

4300-51

Continued on next page

Entering a Site Name, Continued


Procedure (continued)

Step	Action
4	<p>Press the ENTER NAME key.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300-52</p>
5	Highlight a desired letter or symbol using the arrow keys.
6	<p>Press ENTER.</p> <p>NOTE: Enter numbers from the keypad. Use the Backspace command to delete characters.</p>
7	Repeat steps 5 and 6 until the entire name has been entered.


Setting the Time and Date

Displaying the screen

Follow these steps to display the time and date screen.

Step	Action
1	Press SETUP from the Scope Mode screen.
2	Select item 2, Set Programmable Features, from the Setup Menu.
3	Select item #1, Set Time and Date, from the Set Analyzer Parameters Menu. <u>Result:</u> The following screen will appear.  <small>4300-53</small>

Setting the time Follow these steps to set the time.

Step	Action
1	Press the ENTER TIME key. The menu bar changes to the following.  <small>4300-49</small>
2	Enter the hours, minutes, and seconds, pressing the ENTER key after each number.

Continued on next page

Setting the Time and Date, Continued

Setting the date Follow these steps to set the date.

Step	Action
1	<p>Press the ENTER DATE key.</p> <p>The menu bar changes to the following.</p> <div><div>ENTER</div><div>BACK SPACE</div><div></div><div></div><div></div><div>EXIT</div></div> <p>4300-49</p>
2	<p>Enter the number of the month.</p> <p><u>Example</u>: Enter 1 for January, 2 for February, etc.</p>
3	<p>Press ENTER.</p>
4	<p>Enter the day and the year, pressing the ENTER key after each.</p>


Setting the LCD Light, Audible Alarm and Language

Introduction The settings for the LCD backlight, audible alarm and language are controlled from the Set Programmable Features menu. Pressing the menu item number will change the setting for that function.

Displaying the screen Follow these steps to display the Set Analyzer Parameters menu.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 2, Set Programmable Features. <u>Result:</u> The following screen will appear.

Available in TASKCard V4.0 or higher



LCD backlight auto-shutoff Enabled: The backlight for the LCD display will shut off if no key has been pressed for 15 minutes.

Disabled: The backlight for the LCD display will stay on continuously.

NOTE: The auto-shutoff feature extends the life of the battery and is recommended for use.

Audible alarm When set to ON the unit will beep for each event or error condition.

Select Language Display screens are programmed to appear in English language by default. However, with TASKCard PQLite V4.0 or higher, users may navigate through the menu screens in any of the following languages: French, Spanish, German, Italian. See page 1-2 for the procedures on how to select a new language.

Clearing Memory


Caution Clearing memory deletes all events that are currently saved. To avoid losing data, save all events to a memory card before proceeding.

Precaución Si se despeja la memoria se suprimen todos los sucesos actualmente guardados. Para evitar perder datos, guarde todos los eventos en una tarjeta de memoria antes de proceder.

Mise en garde La fonction d'effacement de mémoire supprime tous les événements sauvegardés au fur et à mesure. Pour éviter toute perte de données, avant de poursuivre sauvegardez tous les événements sur une carte à mémoire.

Vorsicht Durch das Löschen des Arbeitsspeichers werden alle aktuell gespeicherten Ereignisse entfernt. Um einen Datenverlust zu vermeiden, sollten Sie alle Ereignisse vor dem Fortfahren auf einer Speicherkarte speichern.

Procedure Follow these steps to clear memory.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 4, Memory Functions.
3	From the Memory Functions Menu, select item 3, Clear Memory. <u>Result:</u> The following screen will appear. 
4	Press the CLEAR MEMORY key.

NOTE If monitoring is on when memory is cleared, the 4300 will take initial readings for all active channels and save them as events.

Resetting the 4300 to the Factory Configuration

Definition The factory configuration of the 4300 is the default setting of the monitoring setup, input configurations, and programmable features of the 4300 when it left the factory.

List Factory configuration consists of the following.

Item	Factory Setting	See Page
Input Channels Setup	All channels set to on	6-6
Channel D Setting	High range	6-6
Circuit Type	Single phase	6-8
Scale Factors	All set to 1	6-10
Monitoring Setup Thresholds	See table on next page	6-19
Waveform Capture Settings	See table on next page	6-27
Interval for Timed Readings	15 minutes	6-17
Site Name	4300	5-2
Memory Auto-Transfer	Disabled	7-3
Memory Storage Type	Fill and Stop	7-2
Alarm	On	5-6
LCD Backlight Auto-Shutoff	Enabled	5-6
Language	User Selected	5-6

Continued on next page

Resetting the 4300 to the Factory Configuration, Continued

Setup listing

The following table lists the settings for the default setup.


Parameter	Thresholds				Wave Capture	
	Ch A	Ch B*	Ch C*	Ch D	Wave	All Chan
V HI LIM	127	Off	Off	005	Off	Off
V LO LIM	105	Off	Off	Off	Off	Off
V TRANS	100	Off	Off	025	On	On
V THD%	005	Off	Off	Off	On	On
V FREQ SENS	00.5	Off	Off	Off	Off	Off
I HI LIM	Off	Off	Off	Off	Off	Off
I LO LIM	Off	Off	Off	Off	Off	Off
I PEAK	Off	Off	Off	Off	Off	Off
I THD%	Off	Off	Off	Off	Off	Off
I TRANS	Off	Off	Off	Off	Off	Off
WATTS LIM	Off	Off	Off	Off	Off	Off
VA HI LIM	Off	Off	Off	Off	Off	Off
VAR HI LIM	Off	Off	Off	Off	Off	Off
PF LO LIM	Off	Off	Off	Off	Off	Off
V SENS OUT	003	Off	Off	002	On	On
V SENS IN	005	Off	Off	Off	Off	Off
I SENS OUT	Off	Off	Off	Off	Off	Off
I SENS IN	Off	Off	Off	Off	Off	Off
V TRANS%	150	Off	Off	150	Off	Off
I TRANS%	Off	Off	Off	Off	Off	Off
# 03 V HARM	005	Off	Off	Off	On	Off
# 03 I HARM	010	Off	Off	Off	On	Off
TRANS - Transient, HARM - Harmonic, SENS - Sensitivity, LIM - Limit						
*In Single Phase TASKCards, Channels B and C are masked and set to OFF by default						

Continued on next page

Resetting the Unit to the Factory Configuration, Continued

Procedure

Follow these steps to reset the 4300 to its factory configuration.

Step	Action
1	From the Scope Mode screen press SETUP.
2	From the Setup Menu, select item 4, Memory Functions.
3	<p>From the Memory Functions Menu, select item 5, Reset to Factory Configuration.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="672 682 1289 1020"></div> <p>4300-56</p>
4	Press the RESET key.


Checking Site Status

Introduction

The Site Status screen displays information about the monitoring setup and the data that is saved in memory.

Displaying the screen

Follow these steps to display the Site Status screen.

Step	Action
1	From the Scope Mode screen, press VIEW DATA.
2	From the View Data Menu, select item 5, System Status. <u>Result:</u> The following screen will appear.  <small>4300B-502</small>

Site status information

The following table provides a description of each field of the Site Status screen.


Field	Description
Site Name	The name entered in the Set Site/File Name screen. See page 5-2 to change.
First Event	Time and date of the first event in memory.
Setup	The setup name. See page 6-25 to change.
Voltage/Current Channels On	The channels turned on in the Active Channels screen. See page 6-6.
Database	Percentage of database (memory) that is full. Updates automatically as new events are saved.
Auto Transfer File	Indicates status of Auto Transfer feature: Enabled or Disabled. Shows % of usage if Enabled.

Checking 4300 Status

Introduction

The 4300 Status screen displays information about the 4300's hardware.

Screen



4300B-503

Analyzer status options

The following table provides a description of each field of the 4300 Status screen.

Field	Description
Input	<u>Good</u> : Voltage and/or current inputs within specified range. <u>Overrange</u> : Voltage and/or current range for one of the inputs has been exceeded. <u>Overload</u> : Voltage and/or current safety limit for one of the inputs has been exceeded. Turn off power and disconnect the unit.
Memory	<u>xxx</u> : Total amount of internal memory available for data storage. <u>Good</u> : Memory within specification. <u>Fault</u> : Memory corrupted. Call Dranetz.
Host CPU	<u>Vx.x</u> : Version of Host CPU firmware.
ACP CPU	<u>Vx.x</u> : Version of ACP (Acquisition Control Processor) CPU firmware.
Database	<u>Vx.x</u> : Version of event database.
TASKCard	<u>PQLite, SHTME</u> : for Single Phase TASKCards <u>PQLite, HTME</u> : for Three Phase TASKCards

Continued on next page

Running a Self-Test

Introduction The self-test function performs an extensive test of all RAM on the 4300. The test lasts approximately 45 seconds. Only run the self- test during non-critical monitoring times, as no data is acquired during the test.

Caution **Monitoring will be turned off for the duration of the test.**

Precaución **El monitoreo quedará apagado mientras dure la prueba.**

Mise en garde **La surveillance sera mise à l'arrêt pour toute la durée du test.**

Vorsicht **Die Überwachung ist während des Tests ausgeschaltet.**

Procedure Follow these steps to run a self-test.

Step	Action
1	From the Scope Mode screen, press VIEW DATA.
2	From the View Data Menu, select item 5, SITE AND 4300 STATUS.
3	<p>From the Site Status screen, press SELF TEST.</p> <p><u>Result:</u> The following screen will appear.</p> <div><div>May-04-9512:24:00</div><div>RUN SELF-TEST CAUTION! LOSS OF DATA WILL RESULT IF THIS TEST IS SELECTED DURING DATA ACQUISITION. RUN TEST DURING NON-CRITICAL MONITORING TIMES ONLY. * PRESS BEGIN TEST TO CONTINUE. * PRESS EXIT TO ABORT.</div><div>BEGIN TESTEXIT</div></div> <div>4300-59</div>

Continued on next page

Running a Self-Test, Continued

Procedure (continued)

Step	Action
4	<p>Press BEGIN TEST.</p> <p><u>Result:</u> The following screen is displayed for the duration of the test.</p> <div><div>Aug-18-9515:49:39</div><div>RUNNING SELF-TEST PLEASE WAIT...</div></div> <p>4300-60</p>

When test is complete

At the completion of the test, the Site Status screen is displayed. See page 5-11.

Chapter 6

Long-term Monitoring

Overview

When to monitor?

This chapter contains information about how to set up the 4300 for long-term monitoring of an electrical system. You generally monitor a circuit in situations where scope or meter measurements don't give you the data that you need to diagnose a problem. The length of time you monitor a circuit can vary from a few hours to a few weeks depending on your application.

Definitions

Event: Any data that the 4300 saves to memory; usually based on exceeding a threshold.

Parameter threshold: A user entered value that the 4300 compares to a measurement to decide if an event occurs. Also called a limit. For example, if the input voltage is measured as 135 Vrms, and the parameter threshold for voltage is 132 Vrms, the 4300 saves this limit crossing to memory as an event.

Waveform capture: A function that saves the actual voltage and/or current waveforms that occurred at the time of an event.

Setup: A preset condition of parameter thresholds and waveform capture settings for each channel that determines what will constitute an event and what waveform data will be saved when this event occurs.

Setup methods

There are two methods you can use to setup the 4300: Easy Start or Advanced. Easy Start prompts you for information and then sets up the unit automatically. With the advanced method you have total control over all setup functions.

Choosing a setup method

The setup method you choose will depend on your application and your familiarity with the operation of the 4300. The differences between the Easy Start and Advanced methods are discussed below.

Continued on next page

Overview, Continued

Choosing a setup method (continued)

Voltage and current channels: With Easy Start, the 4300's voltage and current channels are turned on automatically when you choose a circuit type. With Advanced, each channel must be turned on individually, but any combination can be used.

Parameter thresholds: With Easy Start, all parameter thresholds are automatically set based on the line voltage and current values that you enter. With Advanced, you must enter all thresholds, but they can be set to any value.

Waveform capture: With Easy Start, only five parameters are turned on. With Advanced, any parameter can be turned on.

In this chapter This chapter covers the following topics:

Topic	See Page
Using Easy Start	6-3
Turning Input Channels On and Off	6-6
Selecting Your Circuit Type	6-8
Scale Factors	6-10
Entering Scale Factors	6-11
Frequency Synchronization	6-13
Setting Sync Parameters	6-15
Changing the Timed Interval Setting	6-17
Editing Parameter Thresholds	6-19
Setting Waveform Capture	6-27
Activating a Setup	6-29
Turning Monitoring On	6-30


Using Easy Start

Easy Start description

Easy Start is a series of screens that prompts you for information about the circuit you will be monitoring. The 4300 then automatically turns on the correct channels, sets the parameter thresholds, and waveform capture settings.

Procedure

Follow these steps if you are using the Easy Start function of the 4300.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	<p>From the Setup Menu, select item 1, Easy Start.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="670 779 1291 1115"></div> <p>4300-62</p>
3	<p>Is the unit connected to a circuit and collecting data?</p> <ul style="list-style-type: none">• If <u>y</u>es, press CANCEL and save data to a memory card before proceeding. See page 7-5.• If <u>n</u>o, press CONTINUE and go to next page.

Continued on next page

Using Easy Start, Continued

Select circuit type

The following screen allows you to select the circuit type you will be monitoring.

```

Sep-14-95                               11:50:47
                                EASY START
PRESS '1' FOR SINGLE PHASE
PRESS '2' FOR SPLIT PHASE
PRESS '3' FOR THREE PHASE DELTA
PRESS '4' FOR THREE PHASE WYE
                                EXIT
  
```

4300-63

! FOR SINGLE PHASE TASKCARD

This screen will not appear, but will continue on to the screen below.

Describe application

The following screen allows you to enter values for your nominal line voltage and current and to monitor neutral to ground.

```

Sep-13-95                               16:08:51
                                DESCRIBE APPLICATION:
                                SINGLE PHASE
                                NOMINAL LINE VOLTAGE: 120.0
                                MONITOR CURRENT ?      ON
                                NOMINAL LINE CURRENT:   30.0
                                NEUTRAL-TO-GROUND:      ON
                                NEXT LINE  ENTER VALUE  ON/OFF  PREV SCREEN  NEXT SCREEN  EXIT
  
```

4300B-601

Press the NEXT SCREEN key to step through the remaining Easy Start screens.

Monitoring combinations

Monitoring Combinations: The following table lists the input channels that will be turned on based on the settings of the two previous screens.

Monitor Current	Neutral to Ground	Single Phase	Split Phase	3 Phase (Wye or Delta)
ON	ON	Va, Vd, Ia, Id	Va, Vb, Vd, Ia, Ib, Id	Va, Vb, Vc, Vd, Ia, Ib, Ic, Id
ON	OFF	Va, Ia	Va, Vb, Ia, Ib	Va, Vb, Vc, Ia, Ib, Ic
OFF	ON	Va, Vd	Va, Vb, Vd	Va, Vb, Vc, Vd
OFF	OFF	Va	Va, Vb	Va, Vb, Vc

Continued on next page

Using Easy Start, Continued

Easy Start setup Parameter thresholds: The following table lists the Easy Start settings for the parameters in the setup. All other parameters are turned off.

Parameter	Setting
V HI LIM	+ 10% from nominal
V LO LIM	- 10% from nominal
V TRANS	150% of nominal
V THD%	10% *
V FREQ SENS	2.0 Hz
I HI LIM	+ 10% from nominal
PF LOW LIM	0.85
V SENS OUT	5
V TRANS%	50% **
I TRANS%	50% **

*Some users prefer not to set an initial parameter value for V THD. They collect and plot data first to get a V THD% trend setting.

**Some users prefer to set the V TRANS% and I TRANS% between 150-200% or a parameter setting not lower than 100%.

Waveform capture settings: The following table lists the parameters that will have waveforms saved to memory when the corresponding threshold is exceeded. All other parameters are turned off.

Parameter	Waveform Capture	Record All Channels
V LO LIM	ON	ON
V TRANS	ON	ON
V THD%	ON	OFF

NOTE: Waveform Capture set to ON means that the waveform for the channel where the event occurred will be saved. Record All Channels set to ON means that waveforms for all channels will be saved when an event occurs.

Example: From the table above, if the V LO LIM limit is crossed on Channel C, then waveform data will be saved for that channel and all other active channels. However, if the V THD% limit is crossed on Channel C, then waveform data will be saved for that channel only.

Turning Input Channels On and Off

Introduction

You must turn on any input channel that will be used for monitoring. If a channel is not turned on, no data will be collected for it.



NOTE: The settings on this screen have no effect on the metering functions of the 4300, except for channel D high and low ranges. The Scope Mode, meter mode, harmonics, and phasor screens will all work normally.

Definition

Input channels are the four voltage and current channels on the rear panel labeled CH A, CH B, CH C, and CH D.

Displaying the screen

Follow these steps to display the Active Input Channels screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select “5. Advanced Setup Options.”
3	From the Advanced Setup Options menu, select “1. Set Input Configurations.”
4	<p>From the Set Input Configurations menu, select “2. Set Active Channels.”</p> <p><u>Result:</u> The following screen will appear.</p> <div></div> <p><u>Result:</u> ! FOR SINGLE PHASE TASKCARD</p> <div></div>

Continued on next page

Turning Input Channels On and Off, Continued

Procedure

Follow these steps to turn on any or all input channels.

Step	Action
1	Press the VOLTS ON/OFF key to toggle the highlighted voltage channel between on and off. NOTE: Channel D voltage has three possible settings: LOW (0.5-20 Vrms), HIGH (10-600 Vrms), and OFF. Pressing this key cycles through the three settings.
2	Press the AMPS ON/OFF key to toggle the highlighted current channel between on and off.
3	Press the NEXT CHAN key.
4	Repeat steps 1 to 3 for each channel.

Where to go from here

Refer to the following table to find the next topic.

IF you want to...	THEN see page
select your circuit type	6-8
enter scale factors	6-11
select sync frequency	6-15
change the timed interval setting	6-17
change the monitoring setup	6-19



Selecting Your Circuit Type

Introduction

You must select a circuit type when you are collecting data for power parameters such as watts, VAs, and VARs. If you don't select the proper circuit type, the ABC values won't be calculated correctly.

Displaying the screen

Follow these steps to display the Circuit Type screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.
3	From the Advanced Setup Options menu, select item 1, Set Input Configurations.
4	<p>From the Set Input Configurations menu, select item 1, Set Circuit Type.</p> <p><u>Result:</u> The following screen will appear using a Three Phase TASKCard.</p>  <p><u>Result:</u> ! FOR SINGLE PHASE TASKCARD</p> 

Continued on next page

Selecting Your Circuit Type, Continued

Procedure

Follow these steps to select your circuit type.

Step	Action																
1	Determine the circuit type that the 4300 is connected to.																
2	Press the function key for the correct circuit type according to the following table: <table><tr><th>IF the 4300 is connected to this circuit type...</th><th>THEN press...</th></tr><tr><td>Single Phase</td><td>Single Phase</td></tr><tr><td>Split Phase</td><td>Split Phase</td></tr><tr><td>Four Wire Wye</td><td>3 Phase Wye</td></tr><tr><td>Floating Delta</td><td>3 Phase Delta</td></tr><tr><td>Delta, One Leg Grounded</td><td>3 Phase Delta</td></tr><tr><td>Open Leg Delta</td><td>Split Phase</td></tr><tr><td>High-Leg Delta</td><td>3 Phase Wye</td></tr></table>	IF the 4300 is connected to this circuit type...	THEN press...	Single Phase	Single Phase	Split Phase	Split Phase	Four Wire Wye	3 Phase Wye	Floating Delta	3 Phase Delta	Delta, One Leg Grounded	3 Phase Delta	Open Leg Delta	Split Phase	High-Leg Delta	3 Phase Wye
IF the 4300 is connected to this circuit type...	THEN press...																
Single Phase	Single Phase																
Split Phase	Split Phase																
Four Wire Wye	3 Phase Wye																
Floating Delta	3 Phase Delta																
Delta, One Leg Grounded	3 Phase Delta																
Open Leg Delta	Split Phase																
High-Leg Delta	3 Phase Wye																
3	Press the EXIT key.																

Where to go from here

Refer to the following table to find the next topic.

IF you want to...	THEN see page
enter scale factors	6-11
select sync frequency	6-15
change the monitoring setup	6-19



Scale Factors

What is a scale factor?	<p>A scale factor is the ratio of the input to output parameter for a particular current transformer (CT) or potential transformer (PT). A scale factor is entered into the 4300 and then multiplied automatically by the measured voltage and current so that the unit displays the correct values.</p> <p>NOTE: If voltage and current connections are made without using any of the above named devices, the scale factor should be set to 1.</p>
When to use	<p>Scale factors must be entered for the following conditions:</p> <ul style="list-style-type: none">• A Dranetz current probe is connected to a permanently installed CT.• The current connections are made using a Dranetz ISO box.• The voltage connections are made using a PT.
Dranetz equipment	<p>When a Dranetz current probe or isolation transformer (model ISO-658-5) is chosen from the Current Probe Selection screen (see page 3-17), the correct scale factor is set automatically and does not have to be entered manually.</p> <p>NOTE: The ISO-658-5 is typically used when connecting to the secondary of an existing current transformer. The scale factor of the existing transformer must be entered in order for the 4300 to make the correct calculation.</p>
Non-Dranetz equipment	<p>Refer to the CT name plate or to the manufacturer's literature to determine the scale factor.</p>
Example calculation	<p>The scale factor for a single CT or PT is calculated from its step-up or step-down ratio.</p> <p>If a current transformer has a step-down ratio of 1000A:5A, therefore: Scale Factor = $1000/5 = 200$</p>

Entering Scale Factors

Range 0.001 to 999,900

Displaying the screen Follow these steps to display the Scale Factors screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.
3	From the Advanced Setup Options menu, select item 1, Set Input Configurations.
4	<p>From the Set Input Configurations menu, select item 3, Set Scale Factors.</p> <p><u>Result:</u> The following screen will appear using a Three Phase TASKCard.</p>  <p>4300B-66</p> <p><u>Result:</u> ! FOR SINGLE PHASE TASKCARD</p>  <p>4300B-603</p>

Continued on next page

Entering Scale Factors, Continued

Procedure

Follow these step to enter scale factors.

Step	Action
1	<p>Press the ENTER SCALE key.</p> <p><u>Result:</u> The menu bar will change to the following.</p> <div><div>ENTER</div><div>BACK SPACE</div><div></div><div></div><div></div><div>EXIT</div></div> <p>4300-49</p>
2	Enter the scale factor for the voltage channel.
3	Press ENTER.
4	Enter the scale factor for the current channel.
5	Press ENTER.
6	Press NEXT CHAN.
7	Repeat steps 2 to 7 for each channel that needs scale factors.
8	Press EXIT.

Frequency Synchronization

Introduction

Normal frequency synchronization (sync) of 4300 analog signal processing circuits is controlled by sampling the external ac signal input on channel A. Loss of external sync causes the 4300 to poll other valid voltage channels (A, B, or C) for an alternate external sync. If none exists, then internal sync is automatically selected.

Depending on the type of circuit configuration, the instrument will attempt to autosearch to sync to any valid voltage channel (see table below). Users may choose to disable the autosearch function and specify sync mode EXT CH D. Typically, external sync on CH D is specified if it is known that the signals on A, B or C are inappropriate for use as a sync source (i.e. the frequency is unstable or DC). A clean 50, 60 or 400 Hz signal can be input to CH D and used as a sync signal.

Failure to connect an external sync or to select an internal sync during current monitoring will result in erroneous data being collected and displayed.

Sync during power-up

On power-up, the 4300 will initially attempt to sync on the channel A input voltage signal. If a valid input is available, then the 4300 will sync in the external mode and will remain in this mode until the sync level is lost.

If channel A sync cannot be acquired, then the next valid voltage channel will be polled to re-initiate external sync in accordance with the following table.

Circuit Type	Valid Voltage Channels for Sync
Single Phase	A, D
Split Phase	A, B, D
3 Phase Delta	A, B, C, D
3 Phase Wye	A, B, C, D

Loss of external sync during power up

If external sync cannot be acquired on any valid channel, then the 4300 will revert to internal sync. The frequency used for internal is entered on the Sync Parameters screen. Refer to page 6-15 for the procedure.

The valid voltage channels will be polled in the background in an attempt to reacquire external sync.

When no external sync signal is found, an error message is displayed to inform you of this condition. The loss of sync is also sent to event memory for future recall.

Frequency Synchronization, continued

Loss of sync during monitoring

If sync is lost during monitoring of out of limit events, the 4300 will attempt to reacquire sync on the present sync channel for one minute. If after one minute sync cannot be reacquired, the other valid channels will be attempted without any delay. If sync cannot be acquired on these channels, then the 4300 will switch to internal sync.

The internal sync in this condition will be the last frequency measured before sync was lost. The internal sync frequency entered in the Sync Parameters screen (see next page) will be used if you change to internal sync or if a valid sync was never acquired.

The one minute time-out simulates a long duration interruption which, in turn, generates a TIMEOUT event that normally permits the 4300 to attempt to sync to another valid channel.

NOTE

Parameters such as energy, harmonics, and other steady state metering data are measured more accurately using averaging. Averaging helps to eliminate the uninteresting and misleading effects of short-term changes. All signals including stable signals can be subject to the effects of noise. Averaging helps to increase the signal to noise ratio in the measurement of stable signals. To fill this requirement, Timed events, Energy parameters and Meter data are constructed from composite cycle data. A composite cycle is a single representative cycle made from the super-imposed average of 64 measurement cycles. At 50/60 Hz, one measurement cycle is one power frequency cycle. At 400 Hz, one measurement cycle is eight cycles. One measurement cycle consists of 128 samples at 50/60 Hz. At 400 Hz, there are 16 samples per power frequency cycle and eight cycles per measurement cycle. A composite is constructed from 64 contiguous measurement cycles.

FAILURE TO SECURE A STABLE SYNCHRONIZATION TO THE MEASUREMENT SIGNAL WILL SERIOUSLY DEGRADE THE ACCURACY OF TIMED EVENTS, ENERGY PARAMETERS AND METER DATA.

In general, if the unit is searching for a sync frequency, the composite meter data will appear lower than the single cycle event or single cycle scope data. For instance, this can occur at generator sites where the frequency stability can vary relative to loading.

Setting Sync Parameters

Introduction The sync parameters consist of the Sync Mode and the Nominal Frequency.

Sync mode Default: EXTERNAL

External: When set to EXTERNAL, the 4300 attempts to sync to an incoming voltage signal as described on the previous two pages.

Internal: When set to INTERNAL, the 4300 uses the nominal frequency when making measurements.

External Channel D: When set to EXT CH D, the 4300 only attempts to sync to Vd.

Nominal frequency The nominal frequency is used when the sync mode is set to internal or if a valid external sync was never acquired.

Default: 60 Hz.

NOTE: You should enter a nominal frequency that matches your line frequency. This ensures that if the 4300 loses external sync, it will have a corresponding internal sync.

Displaying the screen Follow these steps to display the Sync Parameters screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.
3	From the Advanced Setup Options menu, select item 1, Set Input Configurations.

Continued on next page

Setting Sync Parameters, Continued

Displaying the screen
(continued)

Step	Action
4	<p>From the Set Input Configurations menu, select item 4, Set Sync Parameters.</p> <p><u>Result:</u> The following screen will appear.</p> <div><div>Jan-06-9510:37:07</div><div>SYNC PARAMETERS</div><div>SYNC MODE: EXTERNAL</div><div>NOMINAL FREQUENCY: 60.0</div><div><div>SELECT SYNC</div><div>ENTER FREQ</div><div></div><div></div><div></div><div>EXIT</div></div></div> <p>4300-67</p>

Changing the sync mode

Press SELECT SYNC to toggle the sync mode between EXTERNAL, INTERNAL, and EXT CH D.

Changing the sync frequency

Follow these steps to change the sync frequency.

Step	Action
1	Press the SELECT SYNC key to select internal sync mode.
2	<p>Press ENTER FREQ.</p> <p><u>Result:</u> The menu bar will change to the following.</p> <div><div>ENTER</div><div>BACK SPACE</div><div></div><div></div><div></div><div>EXIT</div></div> <p>4300-49</p>
3	<p>Enter the nominal frequency desired using the format xx.xx.</p> <p>NOTE: The range for the nominal frequency is 15 to 450 Hz.</p>
4	Press ENTER.

Changing the Timed Interval Setting


Introduction The Interval For Timed Readings screen allows you to define how often the 4300 saves data automatically when no disturbances occur. This function fills in the gaps between disturbances on the time plot.

What is saved? At the preset time interval, the unit saves the values for all parameters on all active channels. See page 4-5 for the list of parameter values that are saved. Waveform data can also be captured. Use the SELECT WAVE key to specify the waveforms to be saved with the timed event.
NOTE: These waveforms can only be viewed with DRAN-VIEW V2.0 or higher.

Default interval 15 minutes.

Range 5 to 7200 seconds (for V3.5 and higher).

Displaying the screen Follow these steps to display the Interval For Timed Readings screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.
3	From the Advanced Setup Options menu, select item 1, Set Input Configurations.
4	From the Set Input Configurations menu, select item 5, Set Interval For Timed Readings. <u>Result:</u> The following screen will appear. <div data-bbox="680 1451 1284 1766"></div>

4300B-604

Changing the Timed Interval Setting, Continued

Procedure

Follow these steps to change the interval for timed readings.

Step	Action
1	<p>Press SET TIME.</p> <p>The menu bar will change to the following.</p> <div><div>ENTER</div><div>BACK SPACE</div><div></div><div></div><div></div><div>EXIT</div></div> <p>4300-49</p>
2	Enter the number from the keypad.
3	Press ENTER.
4	Press EXIT to activate the new setting and return to the Setups Menu.

NOTE: When the interval setting is changed, a reading is taken.

Editing Parameter Thresholds

Introduction

Parameter thresholds can be edited by two methods: three phase or individual channel. Both screens are identical except that the three phase screen allows you to enter the same value for channels A, B, and C simultaneously.

Threshold list

The following table lists the parameter thresholds and the allowable range for each. The heavy lines separate the parameters into the groups as they appear on screen.

Parameter	Description	Range
V HI LIM	High limit for RMS voltage.	1 to 9,999,000
V LO LIM	Low limit for RMS voltage.	0.1 to 9,999,000
V TRANS	High limit for voltage transients.	5 to 9,999,000
V THD%	High limit for voltage thd.	0.5 to 1000
V FREQ SENS	Frequency sensitivity. <u>Note:</u> Frequency is averaged over 20 cycles.	0.1 to 450
I HI LIM	High limit for RMS current.	0.1 to 9,999,000
I LO LIM	Low limit for RMS current.	0.1 to 9,999,000
I PEAK	High limit for peak current.	0.1 to 9,999,000
I THD%	High limit for current thd.	0.5 to 1000
I TRANS	High limit for current transients.	0.1 to 9,999,000
WATTS LIM	High limit for watts.	0.1 to 9,999,000
VA HI LIM	High limit for VA.	0.1 to 9,999,000
VAR HI LIM	High limit for VAR.	0.1 to 9,999,000
PF LO LIM	Low limit for power factor.	0.1 to 1.0
V SENS OUT	Out of limit sensitivity (above high limit or below low limit) for RMS voltage.	0.5 to 9,999,000
V SENS IN	In limit sensitivity (below high limit and above low limit) for RMS voltage.	0.5 to 9,999,000
I SENS OUT	Out of limit sensitivity (above high limit or below low limit) for RMS current.	0.1 to 9,999,000

Continued on next page

Editing Parameter Thresholds, Continued

Threshold list (continued)

Parameter	Description	Range
I SENS IN	In limit sensitivity (below high limit and above low limit) for RMS current.	0.1 to 9,999,000
V TRANS%	Voltage transient sensitivity when above the limit.	1 to 9,999,000
I TRANS%	Current transient sensitivity when above the limit.	1 to 9,999,000
#nTH V HARM%	High limit for the voltage harmonic specified by “n”.	0.1 to 1000
#nTH I HARM%	High limit for the current harmonic specified by “n”.	0.1 to 1000

NOTE 1: Majority of the parameter thresholds and waveform captures should be left disabled unless you have an application that specifically calls for them.

NOTE 2: V HI LIM must be set at least .1V higher than V LO LIM for each active channel or the entered value will not be accepted. This applies even if one or the other is disabled (XXX), so you may have to enable both in order to see what the actual values are. The same applies to I HI LIM and I LO LIM.

NOTE 3: Enabling waveform capture for V LO LIM and V SENS OUT captures critical information at the start of power loss to the measured circuit.

Viewing present thresholds



Follow these steps to display the Thresholds screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.

Continued on next page


Editing Parameter Thresholds, Continued

Viewing present thresholds (continued)

3	<p>From the Advanced Setup Options menu, select item 2, Set Threshold.</p> <p><u>Result:</u> The following screen will appear using a Single Phase TASKCard.</p>  <p><u>Result:</u> The following screen will appear using a Three Phase TASKCard.</p>  <p>NOTE: This screen allows you to view the present threshold values by pressing the NEXT GROUP and PREV GROUP keys.</p>
---	---

Choosing an editing method

Follow these steps to modify either three phase or individual channel thresholds.

Step	Action
1	<p>Press EDIT SETUP.</p> <p>The following screen will appear.</p>  <p>NOTE: "120 Volt Single Phase" is the setup name for the default setup. To change setup name, follow the procedure on page 6-25.</p>
2	Select item 1 or 2 (turn next page for resulting screens).

Editing Parameter Thresholds, Continued

Identical three
phase thresholds
screen

If you selected item 1, the following screen will appear in a Three Phase TASKCard.

Sep-24-95		17:43:34		
SETUP NAME: 120 VOLT SINGLE PHASE				
THRESHOLD	CH. A	CH. B	CH. C	CH. D
V HI LIM	128.0	XXX	XXX	XXX
V LO LIM	108.0	XXX	XXX	XXX
V TRANS	100.0	XXX	XXX	XXX
V THD %	5.0	XXX	XXX	XXX
V FREQ SENS	0.5	XXX	XXX	XXX
NEXT LIMIT	NEXT GROUP	ENABL/ DISABL	ENTER VALUE	EDIT NAME
EXIT				

4300B-607

Parameter values are displayed for Channels A, B, C and D, whenever available. The xxx string simply means that the parameter function is disabled (to Enable/Disable parameters, see page 6-24).

! FOR SINGLE PHASE TASKCARD

If you selected item 1, the following screen will appear.

Jan-21-95	15:07:51
EDIT SETUP MENU	
SETUP NAME: 120 VOLT SINGLE PHASE	
1. SET	DS
2. SET	THIS OPTION NOT INSTALLED
3. SET	
EXIT	

4300B-606b

Continued on next page

Editing Parameter Thresholds, Continued

Individual channel thresholds screen

If you selected item 2, the following screen will appear in a Three Phase TASKCard.

Sep-29-95		17:06:44			
SETUP NAME:120 VOLT SINGLE PHASE					
THRESHOLD	CH.A	CH.B	CH.C	CH.D	
V HI LIM	128.0	XXX	XXX	XXX	
V LO LIM	108.0	XXX	XXX	XXX	
V TRANS	100.0	XXX	XXX	XXX	
V THD %	5.0	XXX	XXX	XXX	
V FREQ HZ	0.5	XXX	XXX	XXX	
NEXT LIMIT	NEXT GROUP	ENABL/ DISABL	ENTER VALUE	EDIT NAME	EXIT

4300B-608

Parameter values are displayed for Channels A, B, C and D, whenever available. The xxx string simply means that the parameter function is disabled (to enable/disable parameters, see page 6-24).

! FOR SINGLE PHASE TASKCARD

If you selected item 2, the following screen will appear.

Sep-29-95		17:06:44			
SETUP NAME:120 VOLT SINGLE PHASE					
THRESHOLD	CH.A	CH.B	CH.C	CH.D	
V HI LIM	128.0	OFF	OFF	128.0	
V LO LIM	108.0	OFF	OFF	XXX	
V TRANS	100.0	OFF	OFF	100.0	
V THD %	5.0	OFF	OFF	XXX	
V FREQ HZ	0.5	OFF	OFF	XXX	
NEXT LIMIT	NEXT GROUP	ENABL/ DISABL	ENTER VALUE	EDIT NAME	EXIT

4300B-609

Parameter values are displayed for Channels A and D, whenever available. The xxx string simply means that the parameter function is disabled (to enable/disable parameters, see page 6-24).


On the other hand, Channels B and C are masked and set to OFF by default. They do not monitor nor record any data.

Continued on next page

Editing Parameter Thresholds, Continued

Changing a threshold setting

Follow these steps to change a threshold setting.

Step	Action
1	Press the NEXT LIMIT key to move the highlight bar to the desired parameter and channel. NOTE: To enter a value, parameter must be enabled. If XXX is displayed for the highlighted parameter, press ENABL/DISABL.
2	Press ENTER VALUE. The menu bar will change to the following. 
3	Enter the desired value using the keypad. The value of the highlighted parameter must be within the range shown on pages 6-19 to 6-20 or the unit will beep and not accept the value.
4	Press ENTER.

Enabling/Disabling a parameter

Follow these steps to enable/disable a parameter.


Step	Action
1	Press the NEXT LIMIT key to move the highlight bar to the desired parameter and channel.
2	Press ENABL/DISABL. <u>Result:</u> The string XXX will be displayed for disabled parameters.

Continued on next page

Editing Parameter Thresholds, Continued

Changing the setup name

Follow these steps to edit the setup name. The setup name can be up to 20 characters long.

Step	Action
1	<p>Press EDIT NAME.</p> <p><u>Result:</u> The following screen will appear.</p> 
2	Use the arrow keys to move the highlight to the desired character.
3	Press ENTER.
4	Repeat steps 2 and 3 until the full setup name is displayed. Up to 20 characters can be entered.
5	Press EXIT twice, until the ACTIVATE key is displayed.
6	<p>Press ACTIVATE.</p> <p>NOTE: The new setup name will not take effect until the ACTIVATE key is pressed.</p>



NOTE: New parameter thresholds do not take effect until the ACTIVATE key is pressed.

Continued on next page

Editing Parameter Thresholds, Continued

Entering a
harmonic
number

Follow these steps to enter a harmonic number for V HARM or I HARM.

Step	Action
1	<p>Press NEXT GROUP until the following screen appears.</p>  <p>4300B-610</p> <p>! FOR SINGLE PHASE TASKCARD Channels B and C are masked and set to OFF by default.</p>
2	<p>Move the highlight bar to # nn V HARM or # nn I HARM.</p> <p>NOTE: To enter a value, parameter must be enabled. If XXX is displayed for the highlighted parameter, press ENABL/DISABL.</p>
3	<p>Press ENTER HARM#.</p> <p>The menu bar will change to the following.</p> 
4	<p>Enter the number from the keypad. The number for the highlighted parameter must be within the range shown on pages 6-19 to 6-20.</p>
5	<p>Press ENTER.</p>

Saving the
settings

Settings are saved only when the ACTIVATE key is pressed.

Where to go
from here

Refer to the next page to change the waveform capture settings.

Setting Waveform Capture

Definition Waveform capture is a function that saves waveform data when an event is triggered by a threshold crossing. This function can be set so that waveforms from the triggered channel, from all channels, or from no channels are saved.

NOTE: Waveform capture must be individually set for each parameter listed on pages 6-19 to 6-20.

Combinations The following table lists all the combinations available for waveform capture, and describes each setting.

Wave Capture	Record All Channels	Description
ON	ON	Saves waveform data for all channels for the chosen parameter.
ON	OFF	Saves waveform data for the triggered channel only.
OFF	ON	Invalid combination.
OFF	OFF	No waveform data is saved.


Displaying the screen Follow these steps to display the waveform capture screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 5, Advanced Setup Options.
3	From the Advanced Setup Options menu, select item 2, Set Threshold.
4	From the setup screen, press EDIT SETUP.

Continued on next page

Setting Waveform Capture, Continued

Displaying the screen (continued)

Step	Action
5	<p>From the Edit Setup menu, select item 3, Set Waveform Capture.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300B-611</p>

Changing a setting

Follow these steps to change the waveform capture settings.

Step	Action
1	Press NEXT GROUP to display the desired parameter group.
2	Press the NEXT LIMIT key to move the highlight bar to the desired line.
3	Press WAVE ON/OFF to change the setting in the Wave Capture column.
4	Press CHANS ON/OFF to change the setting in the Record All Channels column.
5	<p>Repeat steps 1 to 4 for all parameters that you want to change.</p> <p>NOTE: Waveform capture consumes much more memory than event capture. Careful planning about which parameters you want to capture waveforms for will help you increase the number of events that can be saved in memory.</p>
6	When done, press EXIT.
7	Go to next page.

Activating a Setup

Introduction After you edit the thresholds and/or waveform capture settings, you must activate the setup for these new settings to take effect.

Procedure Follow these steps to activate a setup.

Step	Action																														
1	<p>From the Edit Setup menu, press EXIT.</p> <p><u>Result:</u> The following screen will appear.</p> <div><div>Sep-14-9509:21:45</div><div>SETUP NAME: 120 VOLT SINGLE PHASE</div><table><tr><th>THRESHOLD</th><th>CH. A</th><th>CH. B</th><th>CH. C</th><th>CH. D</th></tr><tr><td>V HI LIM</td><td>128.0</td><td>XXX</td><td>XXX</td><td>XXX</td></tr><tr><td>V LO LIM</td><td>108.0</td><td>XXX</td><td>XXX</td><td>XXX</td></tr><tr><td>V TRANS</td><td>100.0</td><td>XXX</td><td>XXX</td><td>XXX</td></tr><tr><td>V THD %</td><td>5.0</td><td>XXX</td><td>XXX</td><td>XXX</td></tr><tr><td>V FREQ SENS</td><td>0.5</td><td>XXX</td><td>XXX</td><td>XXX</td></tr></table><div><div>NEXT GROUP</div><div>PREV GROUP</div><div>EDIT SETUP</div><div></div><div>ACTI- VATE</div><div>EXIT</div></div><div>4300B-612</div></div> <p>NOTE: If you changed any thresholds, they will be displayed on this screen. You can still cancel any changes that you’ve made by pressing EXIT.</p> <p>! FOR SINGLE PHASE TASKCARD</p> <p>Channels B and C are masked and set to OFF by default.</p>	THRESHOLD	CH. A	CH. B	CH. C	CH. D	V HI LIM	128.0	XXX	XXX	XXX	V LO LIM	108.0	XXX	XXX	XXX	V TRANS	100.0	XXX	XXX	XXX	V THD %	5.0	XXX	XXX	XXX	V FREQ SENS	0.5	XXX	XXX	XXX
THRESHOLD	CH. A	CH. B	CH. C	CH. D																											
V HI LIM	128.0	XXX	XXX	XXX																											
V LO LIM	108.0	XXX	XXX	XXX																											
V TRANS	100.0	XXX	XXX	XXX																											
V THD %	5.0	XXX	XXX	XXX																											
V FREQ SENS	0.5	XXX	XXX	XXX																											
2	<p>Press ACTIVATE.</p> <p><u>Result:</u> Messages at the top of the screen will be displayed in the following sequence:</p> <ul style="list-style-type: none">• Monitoring Off (if monitoring was on)• Sync Acquired, Ch A• Monitoring On. <p>The screen will return to the Setup Menu.</p>																														



Turning Monitoring On

Before you turn monitoring on

No data is acquired (stored) when monitoring is turned off. Before turning monitoring on, connect the 4300 to the circuit. Refer to Appendix F for the correct connection diagram. After connecting to the circuit, clear memory to eliminate extraneous data. Refer to page 5-7.

Procedure

Follow these steps to turn on monitoring.

Step	Action
1	<p>From Scope Mode, press SETUP. <u>Result:</u> The following screen will appear.</p>  <p>4300-75</p>
2	<p>Select item 3, Turn Monitoring On. <u>Result:</u> The following screen will appear.</p>  <p>4300-76</p>
3	<p>Press YES to turn on monitoring.</p>

After you turn monitoring on

After turning monitoring on, do not leave the unit in Scope Mode. Scope Mode uses up a huge amount of processor time and is not designed to monitor events. To ensure proper energy monitoring while there is no user key activity, the Scope Mode screen will automatically time out after 15 minutes to return to the main menu. See page 4-3 for details on Scope Mode timeout.

Chapter 7

Saving Data

Overview

Where you can save data

The 4300 allows you to save data manually or automatically in two places: internal memory or the optional memory card.

Internal memory: Data is always saved automatically in the internal memory when monitoring is on. Data can be saved manually in the internal memory by pressing the SAVE key on the Scope or Meter mode screens.

Memory card: Data is saved automatically on the optional memory card when the Auto-Transfer mode is enabled. It can be saved manually by using the Write Events function on the Memory Card Functions screen.

In this chapter

The following topics are covered in this chapter.

Topic	See Page
Setting Memory Storage Mode	7-2
Automatically Saving Data to a Memory Card	7-3
Manually Saving Data to a Memory Card	7-5


Setting Memory Storage Mode

Introduction The memory storage mode describes how events are saved in the internal memory and on the memory card. There are two settings: **Fill and Stop** and **Overwrite**.

Fill and Stop mode In Fill and Stop mode, the 4300 saves events until memory is full, then stops saving new events. All events in memory are preserved. The memory card operates similarly: once full, no new events will be added.

Overwrite mode In Overwrite mode, the 4300 saves events until memory is full. Then, new events replace the earliest events in the internal memory, deleting them. This mode sacrifices old data to continuously save the most recent events. If Auto-Transfer is enabled, only the internal memory will be overwritten. The Auto-Transfer file on the memory card will fill and stop; it will not be overwritten.

Procedure Follow these steps to change the memory storage mode setting.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 4, Memory Functions.
3	From the Memory Functions menu, select item 4, Set Memory Storage Mode. <u>Result:</u> The following screen will appear. 
4	Press NEXT MODE.
5	Press EXIT.

Automatically Saving Data to a Memory Card

Introduction When the Auto-Transfer mode is enabled, all data stored in the internal memory is transferred automatically to the optional memory card.

NOTE The Auto-Transfer function differs from manually writing to the memory card using the Memory Card Functions screen. Two different file types are created on the card and each is retrieved differently. See page 7-5 for details about manually writing to the memory card.

Enabled When Auto-Transfer is enabled, the 4300 automatically transfers all data from the internal memory to the memory card.

Disabled When Auto-Transfer is disabled, data is saved only in the internal memory.

Auto-Transfer files Filename: The filename for the Auto-Transfer file is *filename.mdb*. Where *filename* is the first eight characters of the Site/File Name. See page 5-2.

Retrieval: Auto-Transfer events can be retrieved with the Read Events From Memory Card function on the View Data Menu. See page 8-3.


Procedure Follow these steps to change the Auto-Transfer setting.

Step	Action
1	Insert a formatted memory card into the right slot on the front of the 4300.
2	From the Scope Mode screen, press SETUP.
3	From the Setup Menu, select item 4, Memory Functions.

Continued on next page

Automatically Saving Data to a Memory Card, Continued

Procedure (continued)

Step	Action
4	<p>From the Memory Functions menu, select item 2, Auto-Transfer Options.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300-78</p>
5	Press ENABL/DISABL to change the Auto-Transfer mode.
6	<p>Press EXIT.</p> <p>NOTE: When Auto-Transfer is enabled, data in the internal memory will immediately be transferred to the memory card. The message “Auto-Transfer in Progress. Please Wait.” will be displayed.</p>


Manually Saving Data to a Memory Card

Introduction

Events and setups can be written to a memory card. The card must be formatted before it can be written to.

Displaying the screen

Follow these steps to display the Memory Card Function screen.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select item 4, Memory Functions.
3	From the Memory Functions Menu, select item 1, Memory Card Functions. <u>Result:</u> A screen similar to the following will appear. 

Formatting a card


Follow these steps to format a card.

Step	Action
1	Insert a memory card. <u>Result:</u> Information about the card will appear on the screen.

Continued on next page


Manually Saving Data to a Memory Card, Continued

Formatting a card (continued)

Step	Action
2	<p>Press FORMAT CARD.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300-80</p>
3	<p>Press YES.</p> <p><u>Result:</u> The message “Formatting and Verifying Data Card. Please Wait.” will be displayed until formatting is complete. The time it takes to format the card depends on the card size.</p>

Writing to a card

Follow these steps to write events or setups to a memory card.

Step	Action
1	<p>Press WRITE CARD.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300B-81</p>

Continued on next page

Manually Saving Data to a Memory Card, Continued

Writing to a card (continued)

Step	Action
2	Press WRITE EVENTS or WRITE SETUPS. NOTE: Pressing WRITE BOTH is equivalent to pressing WRITE EVENTS, then WRITE SETUPS.

Writing events Selecting WRITE EVENTS will write all events that are currently in the internal memory to the memory card.

Writing setups Selecting WRITE SETUPS will write all configurations and threshold setups to the memory card. Configurations and setups include the following:

- Present input channel configuration
- Present circuit type
- Present scale factors
- Thresholds
- Waveform capture settings
- Interval for timed readings
- Site name
- Auto-Transfer setting
- Memory storage mode setting

Error messages and warning If there is insufficient space on the memory card, an “Insufficient space” message will be displayed and a beep will be heard.

Filenames The following files are created on the memory card: *filename.evt* (events) and *filename.set* (setups), where *filename* is the first eight characters of the site/ filename. See page 5-2 about changing the site name.

Chapter 8

Viewing Data

Overview

Types of data displays

The 4300 displays data in three forms: graphic summaries, events, and waveforms.

Graphic summaries: These are plots of many events over time. They can be zoomed in on to show more detail.

Events: These are text descriptions of the events which can be one line in an event report or a whole event details screen.

Waveforms: These are the actual voltage or current waveforms that occurred at the time of an event. One or three cycles are displayed depending on the parameter.

What data to view?

Data can only be viewed from the internal memory, but it can be saved to either internal memory or a memory card (see Chapter 7). Two types of data files can be stored on a card: an Auto-Transfer file and an event file. To view data stored on a memory card, it must first be copied into the internal memory. When data files are copied into the internal memory, any existing data in the internal memory is deleted.

Downloading and viewing data on a computer

DRAN-LINK™ is the communications software used to download events from the PP4300 to the computer. While DRAN-VIEW® is the program required to view data on the computer. Both applications are directly interfaced. See Downloading Events from 4300 to a Computer - Software Requirements on page 8-34 for more information.

Dranetz-BMI is the owner and distributor of the DRAN-LINK™ and DRAN-VIEW® product applications. For pricing and availability, contact Dranetz Customer Service Department at (732) 287-3680 or 1-800-DRANTEC.

Overview, continued

In this chapter This chapter is divided into four sections.

Section	Title	See Page
A	Copying Memory Card Files into Internal Memory	8-3
B	Graphic Summaries	8-9
C	Events	8-18
D	Event Waveforms	8-27
E	Downloading Events from 4300 to a Computer	8-32

Section A

Copying Memory Card Files into Internal Memory

Overview

File types In order to view data that is stored on a memory card, you must first copy it into memory. There are two data files that could possibly be on a memory card: an Auto-Transfer file and an Event file.

Auto-Transfer file: An Auto-Transfer file is created when the Auto-Transfer mode is enabled. See page 7-3.

Event file: An Event file (.evt) is created when you use the Write to memory card function. See page 7-6.

Caution Copying a file from the memory card will delete all data in memory. Save any important data before proceeding. See page 7-5 for information about manually saving your data.

Precaución Si se copia un archivo de la tarjeta de memoria se suprimirán todos los datos en la memoria. Guarde todos los datos importantes antes de proceder. Consulte la página 7-5 para información acerca de guardar sus datos manualmente.

Mise en garde Le fait de copier un fichier à partir de la carte à mémoire entraînera l'effacement de l'ensemble des données de la mémoire. Sauvegardez les données importantes avant de poursuivre. Consultez la page 7-5 pour savoir comment sauvegarder manuellement vos données.

Vorsicht Durch das Kopieren einer Datei von der Speicherkarte werden alle Daten im Arbeitsspeicher gelöscht. Speichern Sie deshalb alle wichtigen Daten, bevor Sie fortfahren. Informationen zum manuellen Speichern von Daten finden Sie auf Seite 7-5.

Copying Memory Card Files into Internal Memory, Continued

In this section The following topics are covered in this section.

Topic	See Page
Reading the Auto-Transfer File From a Memory Card	8-5
Reading an Event File From a Memory Card	8-8

Reading the Auto-Transfer File From a Memory Card

Introduction


The Auto-Transfer file will usually be larger than internal memory. Because of this you will have to read the file two or more times if you want to view all of the data. A screen will appear allowing you to enter the date and time of the first event that you want to view.

NOTE

In order for the 4300 to read the Auto-Transfer file, the site name must match the filename on the memory card.

Displaying the screen

Follow these steps to display the Read Events From Memory Card screen.

Step	Action
1	From the Scope Mode screen, press VIEW DATA.
2	<p>From the View Data Menu, select item 4, Read Events From Memory Card.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="673 993 1289 1329"></div>



4300-83

Continued on next page

Reading the Auto-Transfer File From a Memory Card, Continued

Procedure

Follow these steps to read the Auto-Transfer file on the memory card.

Step	Action
1	<p>Press TRANSFER.</p> <p><u>Result:</u> The following screen will appear.</p>  <p>4300-84</p> <p>NOTE 1: If an error message is displayed, refer to the table on the next page.</p> <p>NOTE 2: The default time and date will be for the first event in the file.</p>
2	<p>Are the date and time correct?</p> <p>If <u>y</u>es, go to step 9.</p> <p>If <u>n</u>o, go to next step.</p>
3	<p>Press SELECT DATE.</p> <p>The menu bar will change to the following.</p>  <p>4300-49</p>
4	<p>Enter the desired starting date, pressing ENTER after each portion of the date.</p>
5	<p>Press SELECT TIME.</p>
6	<p>Enter the desired starting time, pressing ENTER after each portion of the time.</p>

Continued on next page

Reading the Auto-Transfer File From a Memory Card, Continued

Procedure (continued)

Step	Action
7	Press READ EVENTS. NOTE: If the card contains more data than can fit in memory, only as much as possible will be copied. After viewing the initial batch of data, note the date and time of the last event. Enter these values into the starting date and time screen to read the rest of the data.

Error messages The following error messages may be displayed when the TRANSFER key is pressed.

Error Message	Description
MEMORY CARD NOT FOUND! NO DATA TRANSFERRED	No memory card inserted or inserted improperly.
DATA FILE CORRUPTED! NO DATA TRANSFERRED.	The 4300 started to read a memory card file but detected an error in the data.
EMPTY MEMORY CARD DATABASE! NO DATA TRANSFERRED.	A valid database has been saved to the memory card but no events exist.
WRONG DATABASE VERSION! NO DATA TRANSFERRED.	The 4300 cannot read the database version on the memory card.
FILE NOT FOUND! NO DATA TRANSFERRED.	No file with the correct name on the memory card. The present site name must match the filename on the memory card. Memory card files use the first 8 characters of the site name. To change site name, see page 5-2.


Reading an Event File From a Memory Card

Introduction

An event (.evt) file is created on a memory card by pressing the WRITE EVENTS key on the Write Data to Memory Card screen (see page 7-6). This file consists of event data that was manually saved to the memory card from the internal memory.

Reading events

Follow these steps to read event files stored on a memory card.

Step	Action
1	From the Scope Mode screen, press SETUP.
2	From the Setup Menu, select “4. Memory Functions.”
3	From the Memory Functions menu, select “1. Memory Card Functions.”
4	From the Memory Card Functions screen, press READ CARD. <u>Result:</u> The following screen will appear.  <small>4300B-85</small>
5	Press READ EVENTS. This allows selection of the event files stored on the memory card.
6	Highlight the desired file and press SELECT. A screen message is displayed: “Reading in data from the memory card. Please wait.”
7	Press NO from the Select Current Probe(s) prompt.
8	Press EXIT repeatedly until the SETUP menu is displayed.
9	From the SETUP menu, press VIEW DATA.
10	Select items 1-3 as desired. See Sections B through D in this chapter for additional information on the VIEW DATA functions.

Error messages

If an error message is displayed, refer to the table on the previous page.

Section B

Graphic Summaries

Overview

Type of graphic summaries

The 4300 can display two types of graphic summaries: time plots and an event activity plot. Both plots allow you to display an event report.

Time plots: A time plot is a graph of the value of one parameter and channel over time. There are 16 parameters and 4 channels that can be plotted. The time plot displays all data since the memory was cleared and is continuously updated. Other functions allow you to expand both the horizontal and vertical axes so that you can perform detailed analysis. You can also display an event report that lists the events that were used to draw the plot.

Event activity plot: This is a plot of the rate of occurrence for all the events in memory. The horizontal axis can be expanded and you can display an event report for all the events in memory.

In this section

The following topics are covered in this section.

Topic	See Page
Viewing Time Plots	8-10
Selecting a Parameter	8-12
Using Horizontal Zoom	8-13
Changing the Vertical Scale	8-15
Viewing the Event Activity Plot	8-17

Viewing Time Plots


What is displayed on a time plot?	A time plot consists of the timed and threshold events that have occurred since memory was cleared for the parameter displayed above the plot.
Screen redraw	The time plot screen is redrawn every ten seconds.
Horizontal axis	Auto-scaled to display all events of the given type.
Vertical axis	Auto-scaled to the highest and lowest parameter values.
Channels	A, B, C, D, ABC
Parameters	<p>The following parameters can be plotted on the time plot screen.</p> <ul style="list-style-type: none">• V rms• V transient• I rms• I transient• Watts• VA• VAR• Power Factor• V Freq• I Peak• V thd• I thd• V harm#___• I harm#___• K-Factor• V Unbalance

Continued on next page

Viewing Time Plots, Continued

Displaying the screen


Follow these steps to display the Time Plot screen.

Step	Action
1	From the Scope Mode screen, press VIEW DATA.
2	<p>From the View Data Menu, select item 1, Time Plots.</p> <p><u>Result:</u> The following screen will appear.</p> <div data-bbox="669 600 1291 936"></div> <p>4300-86</p> <p>Moves highlight to next channel. ! FOR SINGLE PHASE TASKCARD - NEXT CHAN will automatically select only between Channels A or D</p>

Selecting a Parameter

Procedure

Follow these steps to select a parameter for the analog time plot.

Step	Action
1	<p>From the Time Plot screen, press SELECT PARAM.</p> <p><u>Result:</u> The following screen appears.</p>  <p>4300-87</p>
2	<p>Press NEXT PARAM or PREV PARAM until the desired parameter is highlighted.</p> <p>NOTE: The V and I harmonic numbers that are displayed for parameters 12 and 13 are the ones that were entered in the parameter threshold screen. See page 6-26.</p>
3	<p>Press EXIT.</p>

Using Horizontal Zoom

Introduction

The zoom function allows you to expand the horizontal axis of a time plot in order to see the plot in greater detail. You may repeatedly zoom in on a plot down to the minimum resolution of 0.1 seconds/division.

Once you have zoomed in on the desired time period, you can view individual events that are of the type displayed in the timeplot.

NOTE: Horizontal auto-scaling is disabled while the plot is in zoom mode and after exiting zoom.

How to operate the zoom cursors


The cursors will initially be displayed on the left and right edges of the zoom window.

Press the \longrightarrow key to move the left cursor and the \longleftarrow key to move the right cursor.

Initially, both cursors will move inward. If one is moved so that it meets the other cursor, subsequent presses will move it outward.

Procedure

Follow these steps to operate the zoom function.

Step	Action
1	<p>From the Time Plot screen, press ZOOM.</p> <p><u>Result:</u> The menu bar changes to the following.</p>  <p>The screenshot shows a time plot interface. At the top, it displays 'Feb-16-95' and '16:24:43'. Below this, it says 'TIME PLOT START DATE: Jan-27-94' and 'CHANNEL A RMS VOLTAGE'. The plot area shows a waveform with two vertical cursors. To the left of the plot, it indicates 'HIGH 127.3' and 'LOW 5.062'. Below the plot, it shows '15:53:43' and '1 DAY(S) PER DIV'. At the bottom, there is a menu bar with the following options: 'ZOOM IN', 'ZOOM OUT', a right arrow, a left arrow, 'EVENT REPORT', and 'EXIT'.</p> <p>4300-88</p>

Continued on next page

Using Horizontal Zoom, Continued

Procedure (continued)

Step	Action
2	Select a time period using the zoom cursors.
3	Press ZOOM IN. <u>Result:</u> The portion of the plot between the zoom cursors will now fill the entire screen.
4	Repeat steps 2 and 3 for finer resolution.
5	Press EVENT REPORT to display the first event to the right of the left cursor. See page 8-19.
6	ZOOM OUT re-draws the plot to the previous zoom level.

Exiting

Pressing the EXIT key returns you to the previous screen. The zoom resolution is maintained and auto-scaling is disabled until ZOOM OUT is pressed or you exit the timeplot screen and return. You can view zoomed plots of other channels and parameters.

Changing the Vertical Scale



Introduction

The Set Vertical Scale screen allows you to enter your own values for the high and low limits on the time plot. This stops the vertical axis of the plot from auto scaling. Vertical axis auto scaling will resume when another parameter is selected, or the time plot screen is exited.

The scale values that you set will be retained for plots of other channels of the same parameter.

Procedure

Follow these steps to change the vertical scale of a time plot.

Step	Action
1	<p>From the Time Plot screen, press VERT SCALE.</p> <p><u>Result:</u> The following box will appear in front of the time plot.</p>  <p>4300-89</p>
2	<p>Press SET HIGH.</p> <p>The menu bar will change to the following.</p>  <p>4300-49</p>
3	Enter the high limit using the numeric keypad.
4	Press ENTER.
5	Press SET LOW.
6	Enter the low limit using the numeric keypad..
7	Press ENTER.
8	Press EXIT to accept the settings.

Continued on next page

Changing the Vertical Scale, Continued

Ranges

The ranges for the high and low values on the vertical scale are:

High: 0 to 9.999.000 but not lower than the low limit.

Low: 0 to 9,999,000 but not higher than the high limit.

Viewing the Event Activity Plot


Introduction This screen will display a plot of the frequency of occurrence for all events in memory. The horizontal axis is scaled just as in the time plot screen. You can ZOOM IN down to 0.1 sec/div.

Screen redraw The event activity plot screen is redrawn every ten seconds.

Horizontal axis Auto-scaled to display all events in memory.

Vertical axis Auto-scaled to the highest event occurrence.

Displaying the screen Follow these steps to display the Event Activity Plot screen.

Step	Action
1	From the Scope Mode screen, press VIEW DATA.
2	From the View Data Menu, select item 2, Event Activity Plot. <u>Result:</u> The following screen will appear. <div></div>

Zooming The zoom function works the same as for the time plot, refer to page 8-13 for instructions.

Event report Pressing EVENT REPORT will display a list of all events in memory with the first event to the right of the left hand cursor highlighted.

Section C

Events

Overview

Introduction Events are the basic components of the different types of data that you can view on the 4300. Time plots and the event activity plot are graphic representations of the events in memory. Waveforms are optional; they cannot exist without an associated event. An event can be viewed two ways: as a one-line summary in an event list or a complete description on an event details screen.

Report types There are two types of event lists: the event report and worst case events.

Event report: The event report can either list all events in memory as accessed from the Event Activity Plot screen, or list all of the events that were used to make a particular time plot as accessed from the time plot screen. For example, the event report for a voltage rms time plot would list voltage rms events only; no current, power, harmonic, etc. events would be listed.

Worst case events: This is a list of the four worst events for nine parameters. It is accessed from the View Data menu.

In this section The following topics are covered in this section.

Topic	See Page
Viewing the Event Report	8-19
Event Descriptions	8-20
Viewing Worst Case Events	8-23
Viewing Event Details	8-25
IEEE 1159 Classifications	8-26

Viewing the Event Report

Introduction

The events that are stored in the internal memory of the 4300, or on a memory card, can be viewed by displaying the event report. If you access the report from the Event Activity Plot screen, it is a list of all the events in memory in the order that they occurred. If you access the report from the time plot screen, it is a list of only the events that were used to make the time plot.

NOTE: Events that are saved on a memory card must be read into internal memory before they can be viewed. Refer to page 8-3.

Displaying the screen

You view the event report by pressing the EVENT REPORT key on the Event Activity Plot or Time Plot screen.

The following screen shows an event report accessed from the Event Activity Plot.

Nov-17-95			16:34:36		
EVENT REPORT					
EV. #	DATE	TIME	DESCRIPTION		
0301	11-17-93	16:13:55.00	A WATTS NORMAL		
0302	11-17-93	16:13:56.00	A WATTS LIMIT		
0303	11-17-93	16:13:57.00	A WATTS NORMAL		
0304	11-17-93	16:13:58.00	B RMS SEN OUT		
0305	11-17-93	16:13:58.00	C I TRANSIENT		
0306	11-17-93	16:13:58.00	A WATTS LIMIT		
NEXT EVENT	PAGE DOWN	PAGE UP	WAVE/ DETAIL		EXIT

4300-91

! FOR SINGLE PHASE TASKCARD

Only events from Channels A and D are reported. Channels B, C are disabled.

Report description

Each entry consists of the event number, the date and time the event occurred, and a brief description of the event. Refer to the following pages for descriptions of all the events that can appear in the event report.

WAVE/DETAIL key

Pressing this key displays additional information about the highlighted event as follows:

- If waveform information was saved with the event, the Event Waveform screen will appear, see page 8-28.
- If there is no waveform information, the Event Details screen will appear, see page 8-25.

Event Descriptions

Threshold events

The following events occur when a parameter exceeds a specified limit. The description column contains the name of the threshold that is affected.

Event Message	Description
V TRANSIENT	V TRANS exceeded.
I TRANSIENT	I TRANS exceeded.
PEAK CURRENT	I PEAK exceeded.
V REP. TRANS I REP. TRANS	Generated when V TRANS or I TRANS has been exceeded for 10 successive cycles. Transient events will not be recorded again until a transient sensitivity event has occurred, or the impulse limit has not been exceeded for 10 cycles.
V REP OFF I REP OFF	Return to normal for repeat transient event.
V TRANS SENS I TRANS SENS	Transient sensitivity event while in repeat transient shutdown mode. A transient of 150% (or greater) of the worst transient recorded of the 10 successive transients was detected. This resets the repeat transient detection.
V RMS HIGH	V HI LIM exceeded.
I RMS HIGH	I HI LIM exceeded.
V RMS LOW	V LO LIM exceeded.
I RMS LOW	I LO LIM exceeded.
V RMS SEN IN	V SENS IN exceeded.
I RMS SEN IN	I SENS IN exceeded.
V RMS SEN OUT	V SENS OUT exceeded.
I RMS SEN OUT	I SENS OUT exceeded.
FREQ SENS	V FREQ exceeded.
PF LIMIT	PF LO LIM exceeded.
VA LIMIT	VA HI LIM exceeded.
VAR LIMIT	VAR HI LIM exceeded.
WATTS LIMIT	WATTS LIM exceeded.

Continued on next page

Event Descriptions, Continued

Threshold events (continued)

Event Message	Description
V Hn LIMT	#nTH V HARM% exceeded.
I Hn LIMT	#nTH I HARM% exceeded.
V THD LIMT	V THD% exceeded.
I THD LIMT	I THD% exceeded.

Return to normal events

The following events occur when a parameter value returns to normal.

- RMS NORMAL
 - PF NORMAL
 - VA NORMAL
 - VAR NORMAL
 - WATTS NORMAL
 - THD NORMAL
 - VHARM NORMAL
 - IHARM NORMAL
-

Miscellaneous events

The following are miscellaneous events and their descriptions.

Event Message	Description
MONITOR OFF	Occurs under the following conditions: <ul style="list-style-type: none">• Monitoring turned off from Setups Menu.• Memory is full and set to overflow mode.• Easy start entered.
MONITOR ON	Occurs under the following conditions: <ul style="list-style-type: none">• Monitoring turned on from Setups Menu.• Memory is cleared with monitoring turned on.• Easy start completed.
POWER ON	Occurs after unit completes power-up diagnostics.
POWER OFF	Occurs when unit is turned off.
DATABASE FULL	Occurs when internal memory fills.

Continued on next page

Event Descriptions, Continued

Miscellaneous events (continued)

Event Message	Description
SCOPE SNPSHT	Occurs when the SAVE key on Scope Mode is pressed.
POWER STAT	Occurs for status events relating to the battery or the ac power.
ACP STAT	Occurs for status events related to ACP conditions as follows: <ul style="list-style-type: none"> • Self reset, • Board dead, • Configured, • Failure to start ACP, • Probe connect, • Probe disconnect.
OVERANGE	Input voltage or current exceeds safety rating.
OVERLOAD	Input voltage or current saturates A/D converter.
SYNC LOST	Occurs when unit has lost sync.
SYNC ACQUIR	Occurs when the unit has acquired sync.
INT SYNC OFF	Occurs when internal sync is disabled.
INT SYNC ON	Occurs when internal sync is enabled.
LINE CONFG	Occurs when the circuit type has been changed.
MON RESTORED	Occurs when monitoring is restored after being shut down by the system.
TIMED EVENT	Timeplot point set.
THRESH CONFG	Occurs when threshold value is changed.

Viewing Worst Case Events

Introduction

The Worst Case Events screen displays the four worst values recorded for the parameters listed below while they were out of limits.

- Voltage Transient
- Current Transient
- Under/Over Voltages
- Under/Over Currents
- Voltage Harmonics
- Current Harmonics
- Frequency
- Watts
- Power Factor

Displaying the screen

Follow these steps to view the Worst Case Events screen.

Step	Action																									
1	From the Scope Mode screen, press VIEW DATA.																									
2	<p>From the View Data Menu, select item 3, Worst Case Events.</p> <p><u>Result:</u> The following screen will appear.</p> <div><div>Sep-14-9508:35:01</div><div><div>VOLTAGE TRANSIENTS</div><table><tr><th>EV.#</th><th>DATE</th><th>TIME</th><th>CHAN.</th><th>VALUE</th></tr><tr><td>003</td><td>01-04-93</td><td>10:27:35</td><td>C</td><td>199 UPK</td></tr><tr><td>012</td><td>03-07-93</td><td>07:14:15</td><td>B</td><td>135 UPK</td></tr><tr><td>015</td><td>03-26-93</td><td>14:27:35</td><td>A</td><td>245 UPK</td></tr><tr><td>002</td><td>12-31-92</td><td>07:14:15</td><td>D</td><td>117 UPK</td></tr></table><div><div>NEXT EVENT</div><div>NEXT TYPE</div><div>DETAIL</div><div></div><div></div><div>EXIT</div></div></div></div> <div>4300-92</div> <p>! FOR SINGLE PHASE TASKCARD</p> <p>Only events from Channels A and D are displayed. Channels B and C are disabled.</p>	EV.#	DATE	TIME	CHAN.	VALUE	003	01-04-93	10:27:35	C	199 UPK	012	03-07-93	07:14:15	B	135 UPK	015	03-26-93	14:27:35	A	245 UPK	002	12-31-92	07:14:15	D	117 UPK
EV.#	DATE	TIME	CHAN.	VALUE																						
003	01-04-93	10:27:35	C	199 UPK																						
012	03-07-93	07:14:15	B	135 UPK																						
015	03-26-93	14:27:35	A	245 UPK																						
002	12-31-92	07:14:15	D	117 UPK																						

Continued on next page

Viewing Worst Case Events, Continued

Function keys

The following table provides a description of the functions keys for the Worst Case Events screen.


Key	Function
NEXT EVENT	Moves the highlight.
NEXT TYPE	Displays the worst case events for the next parameter type according to the list on the previous page. NOTE: If there are no events for a given parameter, the message “No Worst Case Events” is displayed.
DETAIL	Displays details of the highlighted event. See page 8-26 for a description of the Event Details screen.
EXIT	Returns to the View Data Menu.

Viewing Event Details

Introduction The event details screen displays additional information about an event.

Displaying the screen From the Event Report screen, press WAVE/DETAIL, or from the Worst Case Events screen, press DETAIL.

Result: A screen similar to the following will appear.



NOTE: If you press WAVE/DETAIL and an Event Waveform screen appears (shown on page 8-28), press DETAIL to display the screen shown above.

Function keys The following table provides a description of the functions keys for the Event Details screen.

Key	Function
NEXT EVENT	Displays the details of the next event on the Event Report or Worst Case Events screen.
PREV EVENT	Displays the details of the previous event on the Event Report or Worst Case Events screen.
DATA	Displays the Event Waveform Data menu. NOTE: This key appears if there is a waveform associated with the event.

NOTE: The Category field is shown for voltage rms return to normal events only and is based on specification IEEE 1159 for voltage disturbances. See table next page.

IEEE 1159 Classifications

IEEE reference The classifications listed below are taken from IEEE Standard 1159, Recommended Practice on Monitoring Electric Power Quality.

Table The table below lists the IEEE 1159 classifications that the 4300 will display for voltage variations.

Category	Typical Duration	Typical Magnitudes
Short Duration Variations <ul style="list-style-type: none"> • Instantaneous <ul style="list-style-type: none"> • Interruption • Sag • Swell • Momentary <ul style="list-style-type: none"> • Interruption • Sag • Swell • Temporary <ul style="list-style-type: none"> • Interruption • Sag • Swell 	1 - 30 cycles 1 - 30 cycles 1 - 30 cycles 30 cycles - 3 sec 30 cycles - 3 sec 30 cycles - 3 sec 3 sec - 1 min 3 sec - 1 min 3 sec - 1 min	< 10% of Vnominal < V low limit > V high limit < 10% of Vnominal < V low limit > V high limit < 10% of Vnominal < V low limit > V high limit
Long Duration Variations <ul style="list-style-type: none"> • Interruption • Overvoltages • Undervoltages 	>1 min >1 min >1 min	< 10% of Vnominal > V high limit < V low limit
$V_{nominal} = \frac{V_{highlimit} + V_{lowlimit}}{2}$		

NOTE: Short duration variations will not be saved as events themselves, but will be recorded and categorized in the return to normal event for the associated channel. Long duration events will cause a TIMEOUT event for the channel that went out of limits.

Section D

Event Waveforms

Overview

In this section The following topics are covered in this section.

Topic	See Page
Viewing Event Waveforms	8-28
Analyzing Event Waveforms	8-30

Viewing Event Waveforms

What is displayed?

The Event Waveform screen displays the actual voltage or current waveforms that occurred at the time of an event. One or three cycles are displayed depending on the parameter.

Waveform analysis


Detailed analysis of each waveform can be performed with the four functions on the Event Waveform Data menu: an all channels, all parameters report; Scope Mode display; voltage and current harmonics display; and voltage and current phasor display.

Three-cycle waveform

Definition: A three-cycle waveform consists of the cycle the event occurred in, plus one cycle before and one cycle after. The three cycles are designated as pre-fault, fault, and post-fault.

Parameters: The following parameters will be displayed as three cycle waveforms: Vrms, Vtransient, Irms, Itransient, Freq, Ipeak, Vsens, and Isens.

Example:




One-cycle waveform

Definition: The voltage or current waveform cycle that is displayed is a composite of the previous second's worth of data.

Parameters: The waveforms for the following parameters will be displayed as composites: Watts, VA, VAR, PF, Vthd, Ithd, Vharm#, Iharm#, Vunbalance, K-factor.

Example:




Continued on next page

Viewing Event Waveforms, Continued

Displaying the screen

Press the WAVE/DETAIL key on the Event Report screen to display the following screen. A composite waveform is displayed.



NOTE: If the Event Details screen is displayed instead of this one, there is no waveform saved with the event.

Function keys


The following table provides a description of the functions keys for the Event Waveform screen.

Key	Function
NEXT EVENT	Displays the next waveform event, based on the events listed in the Event Report.
PREV EVENT	Displays the previous waveform event, based on the events listed in the Event Report.
NEXT CHAN	Displays the next channel's waveform. If no other waveforms are available, the unit will beep.
DETAIL	Displays the Event Details screen. See page 8-25.

Analyzing Event Waveforms

Introduction Event waveforms can be analyzed with the four selections on the Event Waveform Data menu.

Procedure Follow these steps to view waveform data.


Step	Action
1	<p>From the Event Details or Worst Case Events screen, press DATA.</p> <p><u>Result:</u> The following screen is displayed using a Three Phase TASKCard.</p> <div data-bbox="670 756 1291 1092"></div> <p>NOTE 1: The three SELECT keys are available for three-cycle waveforms only.</p> <p>NOTE 2: Items 3 and 4 are available if waveforms were saved for all channels. See page 6-27 for information about setting waveform capture.</p>

Continued on next page

Analyzing Event Waveforms, Continued

Procedure (continued)

Follow these steps to view waveform data.

Step	Action
1 (continued)	<p>! FOR SINGLE PHASE TASKCARD</p> <p><u>Result:</u> The following screen is displayed.</p> <div data-bbox="690 598 1291 913"></div> <p>4300-97</p> <p>NOTE 1: The three SELECT keys are available for three-cycle waveforms only.</p> <p>NOTE 2: Items 3 and 4 are not available since not all Channels are valid in Single Phase TASKCards.</p>
2	Press the key corresponding to the cycle to be analyzed.
3	Select one of the numbered items.

Menu items

The four menu items operate identically to the scope and meter mode screens. Refer to the following pages for detailed descriptions of their functionality.

Item	Description	See Page
1	Scope Mode	4-2
2	Harmonics - V, I, & W	4-8
3	All Channels, All Parameters	4-4
4	Voltage & Current Phasors	4-7

Section E

Downloading Events from 4300 to a Computer

Overview

In this section The following topics are covered in this section.


Topic	See Page
Hardware Requirements	8-33
Software Requirements	8-34
Connection Guidelines	8-36
Downloading Events	8-37

Hardware Requirements

Equipment required

To download events from the PP4300 through the optical port, you must have the following equipment available:

- Personal computer or laptop computer with Windows operating system and a serial communications port.
- Isolated Communications Module (P/N PP4300-RS232)



The ISOLATED COMMUNICATIONS MODULE is a communications media that is used to transfer data (EVENTS) from the 4300 to a personal computer or a laptop. It consists of two parts, the fiber optic cable that goes into the optical port of the 4300, and the 4300RS232 adapter that is terminated by a 9-pin RS232 connector. The RS232 interface is supported using the PC standard serial ports COM1 to COM4.

Software Requirements

DRAN-LINK™ application To download events from the PP4300 through the optical port, you must have the following program available: DRAN-LINK™ 4300 V1.0 communications utility software.

DRAN-LINK 4300 is an easy-to-use Windows application which permits transferring (downloading) stored data from the 4300 to a disk file. Using DRAN-LINK 4300, the datafile can be seamlessly transferred to a viewer such as DRANVIEW. DRAN-LINK 4300 shares a common user interface with other members of the DRAN-LINK family of applications available from Dranetz-BMI. In view of this, menu functions which are not applicable to a particular DRAN-LINK software version are disabled.

DRAN-LINK 4300 communicates with the 4300 via a standard RS-232 serial port on the host computer using the Isolated Communications Module. DRAN-LINK 4300 uses a request/response block transfer protocol with error checking to assure maximum data integrity.

Once data transfer has begun, you can work with other Windows applications while DRAN-LINK 4300 runs in the background. Data transfer rate is at 19200 bits per second.

DRAN-VIEW® application DRAN-VIEW® is a Windows 3.1/Windows 95 and Windows NT compatible program that is used to access and retrieve data from data files on a memory card (requires PCMCIA slot or memory card reader) or from other disk media compatible with MS-Windows operating system. Following are the features and highlights of DRAN-VIEW® application:

- Direct interface with DRAN-LINK communications software
- Two-pane browser (timeplots and waveforms simultaneously)
- Multiple ZOOM levels (up to 15 times)
- Advanced Harmonic analysis (DFT/FFT) featuring phasor diagrams and flexible data presentation
- Toolbar and Button support
- Drop-down Events list
- Multi-parameter time plots
- Time measurement tool (delta measurement)
- Saves data to .DNV (DRAN-VIEW compressed format) or converts to ASCII
- Status bar displays time, date and selected pane parameters
- Accelerator keys and right mouse button support
- Cut and paste to other applications
- Email .DNV data files directly from DRAN-VIEW

Software Requirements, Continued

DRAN-VIEW® application (continued)

DRAN-VIEW® is a tool for viewing data on a computer from the following Dranetz-BMI analyzers and TASKCards:

- Power Platform® PP4300 with TASKCard PQLite and TASKCard 808
- Power Platform® PP1 with TASKCard PQPlus and TASKCard Flicker
- 658 PQ Analyzer
- DRAN-LOGGER® DL1, DL1-T

DRAN-VIEW® application packages include DRAN-VIEW *Pro* and DRAN-VIEW Report Writer.

The following features are available only in DRAN-VIEW *Pro*:



- File Append
- Harmonic and 3D timeplots
- Statistics Table with timeplots containing min, max, weighted median, standard deviation, 5%, 95%, and 99% figures.
- Report Writer (though the standard version of DRAN-VIEW may be upgraded to include Report Writer by installing a Report Writer Driver provided on a separate diskette)

For more information about the DRAN-LINK™ and DRAN-VIEW® product lines, contact Dranetz Customer Service at (732) 287-3680 or 1-800-DRANTEC.

Connection Guidelines

Procedure

Follow these steps to connect the 4300 to the computer.

Step	Action
1	<p>Plug the fiber-optic connector on the Isolated Communications Module into the mating connector on the 4300.</p> <p>NOTE: The connector is polarized, and can only be inserted one way. You will feel a slight click when the connector is fully engaged. Do not use force to engage connectors.</p>  <p>The diagram shows a fiber-optic connector labeled 'ISOLATED COMMUNICATIONS MODULE' with an arrow pointing to a port on a device labeled 'PP4300'.</p>
2	<p>Insert the 9 pin DB-9 connector into the appropriate serial port connector on the PC.</p>  <p>The diagram shows a 'PERSONAL COMPUTER' with a 'SERIAL PORT' and an 'RS232 TERMINATOR' connector being inserted into it.</p> <p>NOTE: Depending on the type of computer you are using, the connector may be identified as COM1, COM2, SERIAL or similar. If your computer has a 25 pin serial connector, you will need an appropriate 9 pin to 25 pin adapter. Do not use a NULL MODEM adapter. DRAN-LINK™ supports the use of COM1 to COM4 for communication with the 4300. DRAN-LINK™ auto detects a connected device once the download has started.</p>

Downloading Events

With DRAN-LINK™ 4300 you can choose to download data from the PP4300 Internal Memory or from a Memory Card (if one is installed).

Downloading Events from Internal Memory

Download Internal Memory command (Communicate Menu / Link)

DRAN-LINK™ 4300 will prompt for a file in which to save the download data using a File Save dialog. Once a filename has been specified, DRAN-LINK 4300 attempts to establish communication with the 4300, and if successful, begins transferring data to the file.

DRAN-LINK 4300 displays a progress indicator window during the transfer operation. The window has a CANCEL button to permit termination of data transfer.

Downloading data from the Internal memory of the 4300 takes about 3 minutes.

Downloading Events from Memory Card

Download Memory Card command (Communicate Menu / Link)

DRAN-LINK™ 4300 will prompt for a file in which to save the download data using a File Save dialog. Once a filename has been specified, DRAN-LINK 4300 attempts to establish communication with the 4300, and if successful, begins transferring data to the file.

DRAN-LINK 4300 displays a progress indicator window during the transfer operation. The window has a CANCEL button to permit termination of data transfer.

Downloading the data from the External memory of the 4300 takes about 20 minutes for a typical 2MB memory card.

DRAN-LINK 4300 produces a message display to signal the end of the transfer operation. DRAN-LINK 4300 also produces a message display if the 4300 reports an error or the transfer operation is aborted at the 4300.

NOTE: Do not attempt to save the datafile on a floppy disk. The amount of data that is transferred from the memory card will exceed the capacity of a floppy disk and produce a disk full error during the transfer.

It is recommended to upgrade your TASKCard PQLite version to at least V3.8 to ensure a faster and more reliable download.

Appendix A

Optional Accessories

Overview

Introduction

This appendix is divided into two sections.

Section A provides a general listing of the various optional accessories available for use with the PP4300. It features basic descriptions of some of the optional accessories.

Section B provides detailed discussion on the CompactFlash memory card - the optional accessory that replaces the old model memory card. Discussion includes upgrade features as well as instructions on how to use the CompactFlash with the PP4300 and with TASKCard PQLite version 4.2 or higher.

In this appendix This Appendix is divided into two Sections.

Section	Title	See Pages
A	Accessory List and Descriptions	A-3
B	CompactFlash Card	A-9

Section A

Accessory List and Descriptions

Overview

Introduction This Section lists the optional accessories that are available for the 4300. Descriptions for some of the accessories are given after the list.

In this section The following topics are covered in this section.

Topic	See Page
Optional Accessories List	A-3
Optional Accessories Descriptions	A-5

Optional Accessories List

Accessory	Part Number
Adapter Cable, 658 Current Probe to 4300	CA-4300
Battery Pack (7.2V at 1.6A)	BP-4300
Current Probe, 1 to 500 A	TR2500
Current Probe, 0.1 to 10 A	TR2510
Current Probe, 10 to 3000 A	TR2520
Current Probe, 0 to 30 A	TR2021
Current Probe, 1 to 300 A	TR2019B
Current Probe, 10 to 1000 A	TR2022
Current Probe, 10 to 3000 A	TR2023
DRAN-VIEW PC Software	DV4300
External Battery Charger	XBC-4300
Field Handbook for Electrical Energy Management	HB114415
Field Handbook for Power Quality Analysis	HB114414
Heavy-Duty Cable Set	116087-G1
Isolated Communications Module	PP4300RS232
Isolated Current Transformer	ISO-65X-5
CompactFlash Memory Card	FLASHCARD-32M
CompactFlash Card Reader, USB port	FLASHREADER-USB
CompactFlash Card Reader, Parallel port	FLASHREADER-P
Memory Card, 2M	CARD-2M
Memory Card, 4M	CARD-4M
Memory Card Reader, Data Bus Plug-in	115752-G1
Memory Card Reader, Parallel Port	115751-G1
Memory Card Reader, Parallel Port, E-EU	115751-G2
Memory Card Reader, Parallel Port, E-UK	115751-G3
Memory Card Reader, Serial Port	115750-G1
Memory Card Reader, Serial Port, E-EU	115750-G2
Memory Card Reader, Serial Port, E-UK	115750-G3
Portable Field Printer	PFP-4300
Reusable Shipping Container	RSC-4300
Soft Carrying Case	SCC-4300
TASKCard-808	TASK-808

Optional Accessories List, Continued

Accessory	Part Number
TASKCard-PQLite Single Phase	PQLITE HTEM/1PHASE
TASKCard-PQLite Three Phase	PQLITE HTEM/3PHASE
Voltage Cable Accessory Pack	VCP-4300
Phase Power Adapter	PPA-PP1-R-115
External Power Supply	116297G1

Optional Accessories Descriptions

Adapter cable, 658 current probes to 4300	This cable allows connection of current probes made for the Dranetz Model 658 to the 4300 current input jacks. See illustration in Chapter 3.
Current probes	<p>Several Dranetz current probes can be used with the 4300: models TR2500, TR2510, TR2520, TR2019B, TR2021, TR2022, TR2023. Typical current probes are illustrated in Chapter 3.</p> <p><u>TR2500, TR2510, TR2520</u>: These models will measure rms currents from 1 to 500 A, 0.1 to 10 A, 10 to 3000 A, respectively. They plug directly into any of the current inputs on the rear panel.</p> <p><u>TR2021, TR2019B, TR2022, TR2023</u>: These four probes are made for the Dranetz model 658 but can be used with the 4300 by using an adapter cable (part number 116002-G1). They can measure rms currents in ranges of 0 to 30 A, 1 to 300 A, 10 to 1000 A, and 10 to 3000 A, respectively, and are needed to accurately measure transients.</p>
Field Handbook for Electrical Energy Management	This reference handbook provides a comprehensive guide for information related to conducting a thorough energy audit, power distribution analysis, and methods of remedying inefficiencies of energy management.
Field Handbook for Power Quality Analysis	This handbook is divided into six sections containing step-by-step instructions for discovering and solving complex power quality problems. Example waveforms and case studies are included.
External Battery Charger	The XBC-4300 charges a battery pack while the 4300 is in use.
Heavy duty cable set	Consists of: one red, one yellow, one blue, and five black measurement cables, each eight feet long, and two blue or black jumper cables, each one foot long.

Optional Accessories Descriptions, Continued

Isolated Communications Module	An optically isolated device using infrared light to transfer text and graphics to a PC or printer. Connects the optical serial port on the 4300 to a standard RS232 serial port. Can be connected to a PC using DRAN-LINK™ and DRAN-VIEW® software or to an EPSON graphics compatible printer.
Isolated Current Transformer	Allows the connection of other industry-standard 5 A output current transformers to Dranetz equipment.
CompactFlash Memory Card (new model)	TASKCard PQLite V4.2 or higher support the use of CompactFlash cards. CompactFlash has a more robust data handling and storage capability than the old model memory cards. It is available in sizes ranging from 8MB to 32MB. See page A-9 for details.
Optional CompactFlash card readers	Two types of card readers are available for easy data manipulation and data transfer from the CompactFlash card to the computer: USB port (FLASHREADER-USB) or Parallel port (FLASHREADER-P). For pricing and availability, contact Dranetz Customer Service department at 732-287-3680.
Memory card (old model)	Several sizes of memory cards are available, from 2MB to 4MB. The memory card is read by the optional memory card reader.
Memory card readers	Three types of memory card readers are available as options. Each reader provides a different means of communications with an IBM compatible computer. The three types are: RS232 serial port, parallel port, and data bus plug-in. Memory card readers for the serial port and the parallel port are further modified and made available in Standard, European (EU) and UK versions.
Portable Field Printer	Used for printing 4300 screens. Connects to the 4300 using the Isolated Communications Module.
Reusable Shipping Container	Lockable, high-impact plastic case with foam insulation for protecting the 4300 during shipping.
Soft Carrying Case	Heavy-duty, padded, nylon carrying case. Includes pockets for cable set, current probes, and other accessories.

Optional Accessories Descriptions, Continued

TASKCard 808	This TASKCard changes the 4300 to a power quantity monitor so that it measures, records, and displays electric power parameters such as demand, energy, and power factor. This can help you cut costs by identifying equipment that is operating inefficiently.
---------------------	---

TASKCard PQLite

The PQLite TASKCard is available in two model configurations:

PQLite HTEM 1 Phase (Single Phase): This TASKCard turns the 4300 into a power quality monitor that records sags, swells, interruptions, transients, and power. It provides full power quality and harmonics monitoring for two (2) active channels (V/I) and neutral (V/I). From the four A, B, C and D Channel connectors found in the 4300 instrument, only Channels A and D are valid when using Single Phase TASKCards. Channels B and C are masked and set to OFF by default. The Single Phase TASKCard can measure, record and analyze up to sixteen (16) power quality parameters. It has memory card functions that allow data to be saved to an optional memory card manually, automatically, or both. The DRANETZ-BMI TASKCard system allows users to easily and cost-effectively upgrade the 4300 instrument by simply switching from a Single Phase to a Three Phase TASKCard.

PQLite HTEM 3 Phase (Three Phase): This TASKCard turns the 4300 into a power quality monitor that records sags, swells, interruptions, power, harmonics and transients. It incorporates all previous individual TASKCard PQLite/H-T-M (harmonics, transient capture, memory) functionalities, plus demand and energy recording. The Three Phase TASKCard provides for eight (8) channel monitoring (4V/4I) of power quality, harmonics and energy. All four A, B, C and D Channel connectors are valid and enabled when using Three Phase TASKCards. It also has memory card functions, which allow data to be saved to an optional memory card manually, automatically, or both.

Voltage Cable Accessory Pack

Contains one, single phase measurement cable which allows measurement of a single phase circuit using a standard 115 Vrms AC outlet, and four jumper cables which allow easy interconnection of the measurement cables.

Optional Accessories Descriptions, Continued

**Ordering
information**

To order accessories contact Dranetz Customer Service Department at:

Dranetz-BMI

Tel: (732) 287-3680

1000 New Durham Road

Tel: 1-800-372-6832

Edison, NJ 08818-4019 USA

FAX: (732) 248-1834

Attention: Customer Service

www.dranetz-bmi.com

Section B

CompactFlash Card

Overview

Introduction This Section focuses on the optional accessory that can be used to replace old model SRAM memory cards - the CompactFlash cards. CompactFlash can be used with TASKCard PQLite V4.2 or higher. Upgrade features as well as instructions on how to use the card with PP4300 and TASKCard PQLite V4.2 are discussed.

In this section The following topics are covered in this section.

Topic	See Page
CompactFlash Card Power Features	A-10
Using CompactFlash Card with the PP4300	A-11
Using Compact Flash Card with TASKCard PQLite V4.2 or higher	A-12

CompactFlash Card Power Features

Key Features



The sleek, versatile CompactFlash Card replaces the optional SRAM memory data card and is now available for use with the PP4300. TASKCard PQLite V4.2 or higher support the use of CompactFlash cards. This new model memory card has a more robust data handling and storage capability and has the following key features:

- Increased data storage size - from 8MB to 32 MB
 - Allows auto transfer files of up to 8MB
 - Allows storage of multiple data files
 - Improved speed performance during formatting and file creation
 - Reduced cost
-

Using CompactFlash Card with the PP4300

Procedures

Follow these steps to use the CompactFlash card with the 4300 unit.

Step	Action
1	<p>Insert the CompactFlash card to the PCMCIA Adapter.</p>  <p>CompactFlash Card PCMCIA Adapter</p>
2	<p>Insert the PCMCIA (with the CompactFlash) fully into the data card slot of the PP4300 until resistance is felt.</p> 
3	<p>Press firmly until card engagement is felt.</p> <p>NOTE: Do not force the card further into the slot if no card engagement is felt. Remove card and check if there is foreign object on or in the plug end of the card. Remove any obstruction. Reinsert card and repeat card engagement. If card cannot be engaged, stop all further action and call Dranetz Service for assistance.</p>

Using CompactFlash Card with TASKCard PQLite V4.2 or higher

Auto-transfer functions

TASKCard PQLite V4.2 or higher treats the CompactFlash card like a floppy disk storing files in DOS format. For successful card data transfer, keep the following points in mind:

- PQLite V4.2 supports a maximum DOS directory size of 32MB. If you use up more than 32MB, the card will be formatted to use up to 32MB space and will render the remaining space unusable.
- The maximum size for auto-transfer file has increased from 4MB to 8MB. CompactFlash cards allow you to store multiple auto-transfer files in one card. The Site ID will be used as the filename (i.e. if the site name is SITE_1, the filename will be SITE_1.MDB). To create auto-transfer files, see Automatically Saving Data to a Memory Card on page 7-3.
- PQLite V4.2 does not support file fragmentation. When creating an auto-transfer file, it will look for a contiguous block of 8MB and use that size block for data storage. If the remaining space is less than 8MB, it will use the largest block it can find that is greater than 1MB. If you use a block less than 8MB, the card may be fragmented and you may not get optimum results or lose data. Deleting files from the memory card on the 4300 is NOT RECOMMENDED. Whenever possible, reformat the card using the PP4300 when there is no more space available to begin new data storage.

Manually saving data files

Events and setups can be written to a memory card. The card must be formatted before it can be written to.

To manually save a data or setup file, see Manually Saving Data to a Memory Card on page 7-5.

Appending data files

The File Append feature is available only using DRAN-VIEW *Pro*.

The DRAN-VIEW *Pro* package allows several files to be merged into one DRAN-VIEW DNV file. Use this command to add another database file (DNV, MDB or EVT) to the active document. After the APPEND process, the document will contain data from two individual data files in a single file. Another APPEND can be issued to add data from a third data file into the

Continued on next page


Using CompactFlash Card with TASKCard PQLite V4.2 or higher, Continued

Appending data files (continued)

document and so on. The data from the individual files will be inserted according to their timestamps. If two data sources overlap (in time), then the file with the most recent starting time will have priority and therefore overwrites existing data.

NOTE: Dranview Version 4.0 cannot append files that do not contain waveforms.


Procedure

Step	Action
1	Load the MDB/EVT or DNV file where you want to add another file into, using the normal File-Open command. This initial file will be referred to as the <i>Document</i> in the following steps.
2	Make sure that the target document has been selected on the screen, and then run the File-Append command. This will bring up a dialog box that looks like a File-Open dialog. Select the MDB, EVT or DNV file you want to insert into the target document.
3	<p>The following dialog box shows the relationship of the two files. If the bars overlap, then the oldest file will have its data removed in favor of data in the newest file in the overlap region.</p>  The image shows a Windows-style dialog box titled "Append files". It contains a blue cross icon and text explaining the function: "This function appends the data from another file to the contents of the document file. If the data overlap the data with the newest starting time range have priority." Below this, there are two time range fields. The first field, labeled "Time range of data in the document file:", shows the range "1996-04-24 14:36:57,00 - 1996-04-24 15:23:57,00" with a red bar underneath. The second field, labeled "Time range of data to be appended with the document file:", shows the range "1995-12-12 11:12:40,00 - 1995-12-12 11:17:53,00" with a green bar underneath. The two bars overlap. At the bottom right are "Append" and "Cancel" buttons.

Continued on next page

Using CompactFlash Card with TASKCard PQLite V4.2 or higher, Continued

Procedure (Continued)

Step	Action
4	<p>Press Append to start the conversion.</p> <p>You may now save the document into a new disk file with a new name so the original data is not overwritten.</p> <p>NOTE 1: EVT/MDB files will never be modified by this operation. Only the DNV file is changed. If you take a close look in the event list, you will see a new type of event that indicates where in time the newest file starts (Event number 72 in the example below).</p>  <p>The new “File Join” event contains a complete set of instrument configurations. When you select the first event of the joined file, DRAN-VIEW uses the “File Join” event to insert the instrument configuration context that existed for the joined event file rather than using the old, possibly invalid configuration. This is shown easily by using the View-Instrument Config command on the event before the Join Event, and then looking at it again when selecting an event following the Join Event.</p>

Continued on next page

Using CompactFlash Card with TASKCard PQLite V4.2 or higher, Continued

Procedure (Continued)

Step	Action
4 (continued)	<p>As an example, the Site Information String (&s) that you may include in your chart footers may change when DRAN-VIEW comes to the “File Join” event. This demonstrates that the “Join Event” contains both the instrument and the DRAN-VIEW setups of the joined file.</p> <p>NOTE 2: This command is provided primarily as a means to join (concatenate) and merge databases of similar content and origin. There will be some data loss in the older file in regions of data overlap. Some caution is indicated to help avoid unexpected or nonsense results. For instance, combining a 658 with a PP1 PQPlus database is not recommended. This command is best used when appending files measured with the same instrument and on the same measuring point. At minimum, append only those files that have the same line frequency. There is no theoretical limitation on how many files may be appended. There is however a theoretical limitation of 32000 events in a DNV file. Before reaching these 32000 events, you will find that DRAN-VIEW starts to become slower and slower due to the huge amount of data. The practical limitation depends on the performance of your computer.</p>

For information on the DRAN-VIEW® and DRAN-VIEW *Pro* software package, see Chapter 8 Viewing Data: Downloading Events from 4300 to a Computer - Software Requirements on page 8-34.

Appendix B

Technical Specifications

Overview

In this appendix The following specifications are covered in this appendix.

Topic	See Page
General	B-2
Interfaces	B-3
Measured Parameters	B-4
Computed Parameters	B-6
TR2500 Current Probe	B-8

General

Dimensions	<u>Size:</u> 12" Width x 2.5" Height x 8" Depth (30 x 6.4 x 20.3 cm)
	<u>Weight:</u> 5 pounds (2.2 kg)
Environmental	<u>Operating:</u> 5 to 45 °C (41 to 113 °F)
	<u>Storage:</u> -20 to 55 °C (-4 to 131 °F).
	<u>Humidity:</u> 10% to 90% non-condensing.
System Time Clock	Crystal controlled. 1 second resolution. Event time clock displays to 10 msec resolution. Time displayed in 24 hour format HH:MM:SS. Accurate to 60 seconds per month.
Memory	280 kbytes of standard non-volatile data RAM (event storage). 256 kbytes of standard volatile data RAM (system memory). 256 kbytes of program EEPROM (system memory).
CompactFlash Memory Card (new model)	Sizes range from 8Mbytes to 32 Mbytes. TASKCard PQLite V4.2 or higher support the use of CompactFlash cards.
Memory Card (old model)	2Mbytes to 4 Mbytes depending on the optional memory card capacity.
Power Requirements	<u>Voltage:</u> 12 Vdc.
	<u>Consumption:</u> 18 watts max.
Input resistance	<u>Voltage input:</u> 8 M Ω
	<u>Current input:</u> 200 k Ω

Interfaces

**Installation
Categories**

Mains supply: Installation Category II, Pollution Degree 2

Measurement inputs: Installation Category III, Pollution Degree 2

Display

Type: Negative Transmissive Liquid Crystal Display (LCD) with Electroluminescent (EL) backlighting.

Resolution: 240 x 128 dot matrix.

Size: 4.25 x 2.27 inches (10.8 x. 5.8 cm).

Alarm

Audible alarm of short (approximately 0.1 second) or long (approximately 1 second) duration to call attention to an error condition or event trigger, respectively.

Measured Parameters

Voltage

Four fully differential voltage channels.

Channels A,B,C range: 10-600 Vrms max.

Channel D low range: 0.5-20 Vrms max.

Channel D high range: 10-600 Vrms max.

Crest factor: Maximum 1.7 at full scale.

Accuracy: $\pm 1.0\%$ of reading $\pm 0.05\%$ full scale, with input $> 10\%$ full scale.

Voltage transients

Channels A,B,C range: 50-1000 Vpk.

Channel D low range: 1-30 Vpk.

Channel D high range: 50-1000 Vpk.

Frequency response: Typically -4dB at 1 μ s for half sine wave pulse.

Accuracy: $\pm 10\%$ of reading $\pm 1\%$ full scale for half sine wave pulses $\geq 10 \mu$ s, with input $> 10\%$ full scale.

Transient Duration: 1 μ sec minimum.

Current

Four independent current input channels.

Channels A,B, C, D range: 10-200% of full scale current probe rating.

Channels A,B,C, D crest factor: Maximum of 3 at full scale.

Accuracy: $\pm 1.0\%$ of reading $\pm 0.05\%$ of full scale, at fundamental frequency, plus current probe accuracy.

Continued on next page

Measured Parameters, Continued

**Current
transients**

Channels A,B,C, D range: 10%-300% CT full scale

Frequency Response: Typically -4dB at 1 μ s for half sine wave pulses plus probe.

Accuracy: $\pm 10\%$ of reading $\pm 1\%$ full scale for half sine wave pulses $\geq 10\ \mu$ s plus probe, with input $> 10\%$ full scale.

Transient Duration: 1 μ sec minimum

Phase

Each voltage/current pair (i.e. Channel A voltage, Channel A current) are sampled simultaneously to preserve phase relationship.

Frequency

Fundamental range: 30-450 Hz (TASKCard dependent)

Accuracy: $\pm 0.2\%$ of reading

Environmental

All specifications are met over the operating range.

Computed Parameters

Update rate	All parameters (except harmonic) are updated once per second. Harmonic based parameters are updated every 5 seconds.
--------------------	--

ABC volts	Calculated as the geometric mean of the three phases. See note.
------------------	---

$$V_{ABC} = \sqrt{(V_A^2 + V_B^2 + V_C^2)/3}$$

ABC amps	Calculated as the sum of the three phases. See note.
-----------------	--

$$I_{ABC} = I_A + I_B + I_C$$

Real power	<p><u>Single Phase</u>: Average of instantaneous power samples taken as the product of voltage and current samples. Includes sign to indicate direction of power flow: + from source to load, - from load to source.</p>
-------------------	--

$$W = (1/N) \sum_{n=1}^N V_n I_n$$

Three Phase: Calculated as the sum of the three phases. Includes sign to indicate direction of power flow: + from source to load, - from load to source. See note.

$$W_{ABC} = W_A + W_B + W_C$$

Accuracy: $\pm 2\%$ of reading $\pm 0.2\%$ of full scale at fundamental frequency.

NOTE: All ABC values are not three phase. They are based on the wiring configuration, which can be single-phase, split-phase, wye, or delta. Totals are based on the number of phases for calculations.

Continued on next page

Computed Parameters, Continued

Apparent power Single Phase: Calculated as the product of voltage rms and current rms.

$$VA = V_{rms} \cdot I_{rms}$$

Three Phase: Calculated as vector sum of VAR_{ABC} and W_{ABC} .

$$VA_{ABC} = \sqrt{VAR_{ABC}^2 + W_{ABC}^2}$$

Accuracy: $\pm 2\%$ of reading $\pm 0.2\%$ of full scale at fundamental frequency.

Power factor Calculated as real power divided by apparent power. Includes sign to indicate leading or lagging load current.

$$PF = W/VA$$

Accuracy: ± 0.05 typical

Reactive power Single Phase: Calculated as vector difference between VA and W. Includes sign to indicate if the reactance is inductive (current lagging voltage) or capacitive (current leads voltage). Positive reactive power is inductive.

$$VAR = \sqrt{(VA)^2 - W^2}$$

Three Phase: Calculated as the sum of the three phases. Includes sign to indicate direction.

$$VAR_{ABC} = VAR_A + VAR_B + VAR_C$$

Accuracy: $\pm 2\%$ of reading, $\pm 0.2\%$ of full scale at power factor = 1.

Environmental All specifications are met over the operating range.

TR2500 Current Probe

Guidelines

To achieve the rated accuracies, follow these guidelines:

- The conductor must be at a right angle to the probe
 - The conductor must be centered in the probe core
 - The jaw contact surfaces must be clean and properly aligned.
-

Specifications

Range: 1 to 500 Arms

Accuracy:

48 to 400 Hz: $\pm 1.5\%$ reading $\pm 0.6A$

400 to 3000 Hz: $\pm 3\%$ reading $\pm 0.8A$

Working voltage: 600 V max.

Frequency range: 48 to 3000 Hz

Output signal: 3 mV/A

Maximum conductor size: 1.18" (30 mm)

Maximum bus bar size: 2.5 x 0.20" (63 x 5 mm)

Phase shift (45 to 1000 Hz):

Less than 4°

Operating temperature: 14 to 122 °F (-10 to 50 °C)

Storage temperature: -40 to 158 °F (-40 to 70 °C)

Dimensions: 2.60 x 7.68 x 1.34" (66 x 195 x 34 mm)

Weight: 14.82 oz. (420 g)

Appendix C

Battery Specifications and Replacement Procedure

Overview

Introduction The internal battery pack used in the 4300 functions as the primary power source and UPS; the memory card contains an easily replaceable battery.

The 4300 CPU contains a storage capacitor for memory backup but is not operator replaceable.

In this appendix The following topics are covered in this appendix.

Topic	See Page
Battery Specifications	C-2
Battery Pack Safety Precautions	C-3
Battery Pack Replacement	C-5
Memory Card Battery Replacement	C-7

Battery Specifications

Battery pack

Location: Battery compartment on the bottom of the unit.

Number of batteries in pack: 6

Type: Sealed, rechargeable NiCad cells

Voltage: 7.2 V dc

Capacity: 1.6 Ah

Length of operation: More than two hours when fully charged.

Suggested replacement interval: Two years.

Part Number: BP4300

NOTE: The length of time that the 4300 can operate on the battery pack degrades over the life of the batteries and the number of charge/discharge cycles.

Memory backup

A storage capacitor on the CPU board is used for backup of the 4300's data, configurations, and setup when the battery pack is removed. The capacitor's charge will maintain memory for two hours. The capacitor is not operator replaceable.

Battery Pack Safety Precautions

WARNING	DO NOT intentionally short circuit the battery pack. The batteries are capable of providing hazardous output currents if short circuited. The Power Platform is equipped with an internal battery charger circuit. Do not attempt to charge the batteries with an external charger other than the Dranetz battery charger, since improper charging could cause battery explosion.
ADVERTENCIA	NO ponga intencionalmente la batería en cortocircuito. Las baterías son capaces de proporcionar corrientes de salida peligrosas si están en cortocircuito. La Power Platform está equipada con un circuito interno cargador de baterías. No intente cargar las baterías con un cargador externo que no sea el cargador de baterías Dranetz, puesto que la carga indebida podría hacer que explote la batería.
AVERTISSEMENT	NE PAS court-circuiter délibérément le bloc-batterie. Lors d'un court-circuit, les batteries risquent d'émettre des courants effectifs dangereux. "Power Platform" possède un circuit de chargeur de batterie intégré. Ne pas tenter de charger les batteries au moyen d'un chargeur externe autre que le chargeur de batterie Dranetz, car un rechargement fautif pourrait entraîner l'explosion de la batterie.
WARNUNG	Die Batterien dürfen NICHT kurzgeschlossen werden. Im Falle eines Kurzschlusses können die Batterien lebensgefährliche Ausgangsströme leiten. Power Platform ist mit einem internen Batterieladegerät ausgestattet. Die Batterien sollten nur mit dem Ladegerät von Dranetz geladen werden. Die Verwendung eines externen Ladegeräts kann zu einer Explosion der Batterien führen.
Battery safety precautions	<p>Observe the following precautions when inspecting or replacing the battery pack:</p> <ul style="list-style-type: none">• Do not attempt to replace individual batteries of the pack or substitute other battery types.• Do not dispose of battery in fire.

Continued on next page

Battery Pack Safety Precautions, Continued

- Dispose of a used battery promptly in accordance with local Environmental Protection Agency (EPA) regulations.
- Visually inspect the battery pack for corrosion:

The batteries have a safety pressure vent to prevent excessive gas build-up and corrosion indicates that venting has occurred. Possible causes of venting are: a defective charger, excessive temperature, excessive discharge rate, or a defective cell.

If corrosion is excessive, the battery pack may require replacement (contact Dranetz Customer Service Department).

Battery Pack Replacement

Introduction The 4300 contains an easily replaceable internal battery pack. See Appendix D for ordering information.

WARNING **Replace with Dranetz Ni-Cad battery pack BP4300 only.**

ADVERTENCIA **Reemplace con batería Dranetz Ni-Cad BP4300 solamente.**

AVERTISSEMENT **Remplacer par la batterie Dranetz Ni-Cad BP4300 exclusivement.**

WARNUNG **Nur mit Dranetz Ni-Cad BP4300 Batteriesatz auswechseln.**

Note During normal operation, the battery pack will be slightly warm to the touch.


Procedure Follow these steps to replace the battery pack.

Step	Action
1	Press the 4300 power key to off.
2	Turn off power to the circuit being measured.
3	Disconnect voltage and current probes from the circuit and the 4300's rear panel.
4	On the bottom of the 4300, push the tab to release the battery cover. Refer to the diagram shown below.
5	Remove the cover.
6	Pull up on removal strap and remove battery pack.
7	Insert the new pack into the compartment making sure to observe polarity markings.
8	Replace the cover and press down until it latches closed.
9	Discard the old battery pack in accordance with Environmental Protection Agency (EPA) regulations.
10	Press the 4300 power key to on.

Continued on next page

Battery Pack Replacement, Continued

Battery removal
diagram



Memory Card Battery Replacement

Introduction	Replacement of the 3-volt lithium battery in the memory card is performed when the battery message in the Memory Card Function screen states the battery is depleted. Replacement is simple and requires no special tools. Two physically different types of batteries are used due to different manufacturers of the memory card. The correct replacement type must be used.
WARNING	The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, or dispose of in fire. Replace battery with Panasonic BR2325 or CR2025 only. Use of another type battery may present a risk of fire or explosion.
ADVERTENCIA	La batería empleada en este dispositivo puede presentar un peligro de incendio o quemadura química si se manipula indebidamente. No recargue, desarme ni deseche en el fuego. Cambie la batería por una Panasonic BR2325 o CR2025 solamente. El uso de cualquier otro tipo de batería puede presentar un peligro de incendio o explosión.
AVERTISSEMENT	La batterie utilisée dans cette unité peut présenter des risques d'incendie ou de brûlures chimiques par suite d'une utilisation abusive. Ne pas recharger, démonter, ni jeter au feu. Remplacer uniquement la batterie par une batterie Panasonic BR2325 ou CR2025. L'utilisation d'un tout autre modèle de batterie peut entraîner des risques d'incendie ou d'explosion.
WARNUNG	Die in diesem Gerät verwendete Batterie kann im Falle einer unsachgemäßen Behandlung zu Bränden oder chemischen Verätzungen führen. Sie sollte nicht wiederaufgeladen, auseinandergenommen oder verbrannt werden. Ersetzen Sie die Batterie nur mit Batterien vom Typ Panasonic BR2325 oder CR2025. Die Verwendung eines anderen Batterietyps kann Brände oder Explosionen hervorrufen.

Continued on next page

Memory Card Battery Replacement, continued

Battery check To check the condition of the memory card battery, perform the following steps.

Step	Action
1	Insert questionable memory card in memory card slot on 4300 and press card in firmly.
2	From the Scope Mode screen, press SETUP.
3	From Setup Menu select 4, Memory Functions.
4	From Memory Functions menu, select 1, Memory Card Functions.
5	Verify Memory Card Battery = OK. If OK, do not replace the battery. If not OK, proceed to replacement procedure.
6	If message says OK, but the memory card is faulty, try a different memory card for operation. If the replacement memory card operates OK, the original memory card is faulty and should be replaced.

Battery types There are two types of physically different memory card batteries. Both batteries are 3-Volt, lithium, wafer type.

Part Number	Diameter	Thickness
Panasonic CR2025	0.79" (20mm)	0.1" (2.5mm)
Panasonic BR2325	0.9" (23mm)	0.1" (2.5mm)

Battery safety precautions The following safety precautions must be adhered to.

- Keep batteries away from children. Never permit a child to play with a battery as an ornament or toy.
- Do not disassemble battery.
- Do not dispose of battery in fire.
- Dispose of a used battery promptly in accordance with local Environmental Protection Agency (EPA) regulations.

Continued on next page


Memory Card Battery Replacement, Continued

Replacement procedure

To remove and replace a memory card battery, proceed with the following steps.

Step	Action
1	Remove memory card from 4300.
2	Refer to figure below. Gently press in battery release with pencil point and remove battery holder.
3	Remove battery from holder and identify the type battery used. If type is not identified on body of battery refer to preceding page for battery dimensions.
4	Insert the exact type replacement battery in holder with plus (+) terminal facing up.
5	Insert battery holder into memory card and press in until locked in position.
6	Dispose of battery promptly. See battery safety precautions above.

Battery replacement diagram



Appendix D

Operator Replaceable Parts List

Introduction The following parts are easily replaced by the operator and do not require special tools or access to the interior of the unit.

To order parts Call Dranetz Customer Service at (732) 287-3680 or 1-800-DRANTEC to order any of the following parts.

Parts List

Part Description	Part Number
AC Adapter/Battery Charger	116297-G1
Battery Door	116037-G1
Battery Pack	BP-4300
Rubber Skin	116035-G1
Voltage Cable Assembly, 4 Pair w/ Alligator Probes (See below for separate parts)	116042-G1

**Measurement
cable set, parts
list**

Part Description	Quantity	Part Number
Alligator Clip, 4MM Plug-on, Red	4	900371
Alligator Clip, 4MM Plug-on, Black	4	900372
1000V Cable, Red	1	900366
Yellow Cable/Plug	1	900367
6FT Cable/Plug Blue, 4300	1	900368
6FT Cable/Plug Gray, 4300	1	900369
6FT Cable/Plug White, 4300	1	900370
Carry Strap	1	116040-G1
Cable Pouch, PP4300	1	116043-G1

Appendix E

System Messages

Overview

Introduction Display messages provide you with 4300 operating information or tell you about an error condition. This appendix describes the types of messages that can appear, lists the messages, and gives instructions about what to do next. Self-explanatory messages are not included.

In this appendix The following topics are covered in this appendix.

Topic	See Page
Message Types	E-2
Messages	E-3

Message Types

Introduction There are three types of messages: Normal One-Line, Important One-Line, and Full Screen. When a message is displayed it is automatically saved to memory for recall at a later time.

One-line messages All one-line messages are displayed on the top line of the screen between the time and date, and are a maximum of 21 characters long. They are displayed as long as the condition exists.

Normal one-line messages: Normal one-line messages are displayed in regular text.

Important one-line messages: Important one-line messages are displayed in reverse video.

Full screen messages Full screen messages warn you of potential system problems. You must press a key to remove the screen message.

Priority In general, a more important message will take priority over a less important one, with the exception of full screen messages which are displayed until you press a key.

When two or more one-line message are active, they are alternately cycled every two seconds. The priority is as follow:

Priority	Description
1	All new one-line messages are displayed immediately, accompanied by a short beep, then normal message cycling is resumed.
2	When there are important one-line messages, only these will be cycled until they are cleared.
3	When there is only one important one-line message displayed, no normal one-line messages will cycle until the displayed message is cleared.
4	No one-line messages are displayed on HELP screens, but full screen messages will operate normally.
5	Full screen messages will always take precedence over any type of one-line display.

Messages

One-line messages

Sync Lost Ch A, B, C, or D.

The unit cannot synchronize to the specified channel. Either no voltage or a voltage outside the sync range is being applied. If the unit continues to switch between Sync Lost and Sync Acquired, you may have to change to internal sync.

Sync Acquired-Ch A, B, C, or D.

The unit has synchronized to the specified voltage channel.

Probe Ch A, B, C, or D-Connect.

A current probe has been connected to the specified channel.

Probe Ch A, B, C, or D-Disconnect.

The current probe on the specified channel has been disconnected.

Volts Overload Ch-A, B, C, or D.

The voltage range for the specified channel has been exceeded.

Amps Overload Ch-A, B, C, or D.

The current range for the specified channel has been exceeded. Use a probe with a range appropriate for your measurements.

Volts Overrange Ch A, B, C, or D.

The voltage safety limit for the specified channel has been exceeded. Turn off power to the circuit and disconnect the unit.

Amps Overrange Ch A, B, C, or D.

The current safety limit for the specified channel has been exceeded. Turn off power to circuit and disconnect the unit.

Continued on next page

Messages, Continued

Full screen message

Battery Low.

The charge on the internal battery is low. The battery pack can be charged by connecting the AC Adapter/Battery Charger to the 4300. A depleted battery pack can be recharged in 2 hours with the unit off and 24 hours with the unit on. The Battery Charge Indicator glows steadily while charging, and flashes when fully charged. The 4300 will always operate on the charger and is designed to do so, regardless of the state of charge of the battery.

TASKCard error messages

The following table describes the possible error messages when loading the TASKCard and the corrective action to take for each.

Error Message	What to do Next
TASKCard Not Found. Please turn off instrument and insert valid Model 4300 card.	TASKCard may not be installed or is installed incorrectly. Turn off power and recheck TASKCard installation.
Corrupt TASKCard. Please Install TASKCard.	A TASKCard was found but it was not recognized as a valid TASKCard. Turn off power and recheck TASKCard. If the TASKCard is properly inserted, there may be a problem. Notify Dranetz for further assistance.
WARNING: The Task Card found: (now installed) Is different than last used: (previous Task Card) CHANGING TASK CARDS MAY ERASE MEMORY!	Press any key to continue or turn off the unit and reinstall the last TASKCard used.
Any of the following: <ul style="list-style-type: none">•DSP Processor Download Failed•DSP Processor Will Not Respond	TASKCard download problem. Notify Dranetz for further assistance.

Appendix F

Common Circuit Connections

Overview

Who should read this section

If you are making power measurements, follow these diagrams so that your ABC values are calculated correctly.

WARNING

Death, serious injury, or fire hazard could result from improper connection of this instrument. Read and understand this manual before connecting this instrument. Follow all installation and operating instructions while using this instrument.

Connection of this instrument must be performed in compliance with the National Electrical Code (ANSI/NFPA 70-2002) and any additional safety requirements applicable to your installation.

Installation, operation, and maintenance of this instrument must be performed by qualified personnel only. The National Electrical Code defines a qualified person as “one who has the skills and knowledge related to the construction and operation of the electrical equipment and installations, and who has received safety training on the hazards involved.”

Qualified personnel who work on or near exposed energized electrical conductors must follow applicable safety related work practices and procedures including appropriate personal protective equipment in compliance with the Standard for Electrical Safety Requirements for Employee Workplaces (ANSI/NFPA 70E-2000) of USA and any additional workplace safety requirements applicable to your installation.

ADVERTENCIA

Una conexión incorrecta de este instrumento puede producir la muerte, lesiones graves y riesgo de incendio. Lea y entienda este manual antes de conectar. Observe todas las instrucciones de instalación y operación durante el uso de este instrumento.

La conexión de este instrumento debe ser hecha de acuerdo con las normas del Código Eléctrico Nacional (ANSI/NFPA 70-2002) de EE. UU., además de cualquier otra norma de seguridad correspondiente a su establecimiento.

La instalación, operación y mantenimiento de este instrumento debe ser realizada por personal calificado solamente. El Código Eléctrico Nacional define a una persona calificada como "una que esté familiarizada con la construcción y operación del equipo y con los riesgos involucrados."

Continued on next page

Overview, Continued

AVERTISSE- MENT

Si l'instrument est mal connecté, la mort, des blessures graves, ou un danger d'incendie peuvent s'en suivre. Lisez attentivement ce manuel avant de connecter l'instrument. Lorsque vous utilisez l'instrument, suivez toutes les instructions d'installation et de service.

Cet instrument doit être connecté conformément au National Electrical Code (ANSI/NFPA 70-2002) des Etats-Unis et à toutes les exigences de sécurité applicables à votre installation.

Cet instrument doit être installé, utilisé et entretenu uniquement par un personnel qualifié. Selon le National Electrical Code, une personne est qualifiée si "elle connaît bien la construction et l'utilisation de l'équipement, ainsi que les dangers que cela implique".

WARNUNG

Der falsche Anschluß dieses Gerätes kann Tod, schwere Verletzungen oder Feuer verursachen. Bevor Sie dieses Instrument anschließen, müssen Sie die Anleitung lesen und verstanden haben. Bei der Verwendung dieses Instruments müssen alle Installation- und Betriebsanweisungen beachtet werden.

Der Anschluß dieses Instruments muß in Übereinstimmung mit den nationalen Bestimmungen für Elektrizität (ANSI/NFPA 70-2002) der Vereinigten Staaten, sowie allen weiteren, in Ihrem Fall anwendbaren Sicherheitsbestimmungen, vorgenommen werden.

Installation, Betrieb und Wartung dieses Instruments dürfen nur von Fachpersonal durchgeführt werden. In dem nationalen Bestimmungen für Elektrizität wird ein Fachmann als eine Person bezeichnet, welche "mit der Bauweise und dem Betrieb des Gerätes sowie den dazugehörigen Gefahren vertraut ist."

Continued on next page

Overview, Continued

WARNING	To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.
WARNING	To reduce the risk of fire, electrical shock, or physical injury it is strongly recommended to fuse the voltage measurement inputs. Fuses must be located as close to the load as possible to maximize protection.
WARNING	For continued protection against risk of fire or shock hazard replace only with same type and rating of recommended fuse. Use only fast blow type fuse which is rated 600V. Recommended fuse type is Littelfuse, part number KLKD0.25 rated 600V AC/DC, 0.25 A fast blow.
WARNING	Do not replace fuse again if failure is repeated. Repeated failure indicates a defective condition that will not clear with replacement of the fuse. Refer condition to a qualified technician.
Safety precautions	<p>The following safety precautions must be followed whenever any type of voltage or current connection is being made to the 4300.</p> <ul style="list-style-type: none">• Wear proper Personal Protective Equipment, including safety glasses and insulated gloves when making connections to power circuits.• Hands, shoes and floor must be dry when making any connection to a power line.• Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.• Set the 4300 power switch to Off.• Before connecting to electric circuits to be monitored, open their related circuit breakers or disconnects. DO NOT install any connection of the 4300 to live power lines.• Connections must be made to the 4300 first, then connect to the circuit to be monitored.

Continued on next page

Overview, Continued

Voltage and current connections

This section contains numerous drawings of both voltage and current probe connections that are required when power measurements are to be made.

Voltage: Voltage probes are connected to the individual source or load line and are referenced to the return (common) line voltage probe connection for greatest accuracy.

Current: Current probes are connected to each line and positioned to measure currents with reference to the voltage probe. Incorrectly positioned current probes may produce erroneous power measurement.

Phasor diagrams

Correct phasor diagrams (for resistive loads) are shown for each connection.

In this appendix The following connections are shown in this appendix.

Topic	See Page
Verifying Voltage and Current Connections	F-5
Single Phase	F-8
Split Phase	F-9
Four Wire Wye	F-10
Floating or Grounded Delta	F-11
Open Leg Delta	F-13
High-Leg Delta	F-14
Connecting to a Potential Transformer (PT)	F-15
Connecting to a Current Transformer (CT)	F-17
Connecting to an Isolated Current Transformer (ISO)	F-19


Verifying Voltage and Current Connections

Introduction Correct voltage and current connection of single phase, split phase, or polyphase connections can be verified using phasor diagrams. Phasors diagrams are graphic representations that show the magnitude and angular relationship of each phase of a monitored connection. Each connection diagram on the following pages shows the correct voltage and current phasor diagrams (for resistive loads) for that circuit.

Displaying the screen Follow these steps to display the Voltage and Current Phasor screen.

Step	Action
1	From Scope Mode, press METER MODE.
2	From Meter Mode, press PHASOR. <u>Result:</u> The following screen will appear using a Three Phase TASKCard. <div><div>Jun-16-9510:42:58</div><div>PHASOR: VOLTS</div><div>A: 115 e 000°</div><div>B: 115 e 240°</div><div>C: 118 e 117°</div><div>D: 0.0 e 270°</div><div><div>120°</div><div>240°</div><div>0°</div><div>C</div><div>B</div><div>H</div></div><div><div>SINGLE CHAN</div><div>NEXT PARAM</div><div>NEXT METER</div><div></div><div>SAVE</div><div>EXIT</div></div></div>

Single phase A single phase voltage or current phasor is displayed as a single line showing a channel reference at 0 degrees and a magnitude relative to its measured value. An arrowhead on the line indicates direction.




Continued on next page

Verifying Voltage and Current Connections, Continued

Split phase Split phase vectors are displayed as dual lines showing channel references and magnitudes and opposite (180 degrees) directions.


Three phase Three phase vectors are displayed as three lines, 120 degrees apart in a resistive load (unity power factor). Phase displacement will occur in a reactive load.

Correct 3-phase voltage phasor connections The voltage phasor display shown below is for a three phase, four wire, wye connection.



4300-43

Correct 3-phase current phasor connections The current phasor display shown below is for a three phase, 4 wire wye connection.




4300-98

Continued on next page

Verifying Voltage and Current Connections, Continued


Incorrect current phasor diagram

The following phasor display shows an incorrect current probe connection. The phasor for channel C is 180° out of phase. This can be corrected by reconnecting the probe so that the arrow on the probe handle points toward the load.



Single channel phasor diagram

The following display shows the voltage and current phasors for channel A.




Single Phase

Introduction When making voltage connections to a single phase circuit use channel A differential inputs as shown below.

NOTE Be sure to connect the current probe with the arrow on the handle pointing towards the load or an erroneous power reading will result.

Connection diagram



Phasor diagrams




Split Phase

Introduction

When making split phase measurements use both channels A and B for voltage and current connections. The neutral is chosen as the reference for measurement purposes.

Connection diagram



4300-26

Phasor diagrams




Four Wire Wye


Introduction

Channels A, B, and C are connected to voltage and current probes. The neutral is connected to common and is the reference for the three channels.

Connection diagram



Phasor diagrams




Floating or Grounded Delta


Introduction

In this power connection, the 4300 uses voltage channels A, B, and C as differential inputs with channel A using source voltage A-B, channel B using B-C, and channel C using C-A as the reference. Current probes are connected to channels A, B, and C.

Connection diagram





Floating delta phasor diagrams




Continued on next page

Floating or Grounded Delta, Continued

Grounded delta phasor diagrams



Setup Procedure for 4300 Delta Configuration


Step	Action
1	Turn OFF all power to the unit and measurement channel inputs.
2	Connect the 4300 voltage and current connections as shown on page F-10.
3	Power ON the 4300 and then turn power ON to the measurement circuits. Select the appropriate current probes (ex. TR2510). Select the circuit type to “Three Phase Delta”. Select the appropriate scale factors (PT and CT ratios).
4	Go to the “Meter Mode” screen (keep pressing “Next Meter” until the phasor screen appears) and verify that the phase sequence of the phasor diagrams for the voltage and current parameters are as shown. If the phase sequence does not match, turn power OFF to the measurement circuits and interchange the voltage and/or current connections. Then turn power ON to the measurement circuits. Verify if the phase sequence appears as shown for a typical A-B-C phase rotation.  <p>The graph titled "4300_Phase_Sequence" displays three sinusoidal waveforms labeled A (red), B (yellow), and C (blue). The x-axis represents time or phase angle from 0 to 30, and the y-axis represents amplitude from -200,000 to 200,000. Waveform A starts at 0, B starts at approximately -150,000, and C starts at approximately 150,000, indicating a positive A-B-C phase sequence.</p>
5	If the voltage and phase sequence do not match, turn power OFF to the measurement circuits and interchange the incorrect voltage and/or current connections. Verify if the phase sequence is correct.
6	Once the phase sequence is correct, you can now begin monitoring.

Open Leg Delta

Introduction


The figure below shows the open leg delta with phase A-C connected to channel A and phase B-C connected to channel B. Current probes are connected to channels A and B.

Connection diagram



4300-23

Phasor diagrams




High-Leg Delta

Introduction


The 4-wire delta connected 120/240V source is connected with one phase connected to ground at mid-point. This phase provides 120V at phases A and C to ground. Phase B is designated as the high-leg connection and is measured at 208V ($120V \times 1.73 = 208V$) to ground. The National Electrical Code (1996 NEC 215-8) identifies the high-leg phase as the orange colored line.

Connection diagram



4300-29

Phasor diagrams



Connecting to a Potential Transformer (PT)

**Safety
Precautions**

Follow the safety precautions listed on page F-3 when making all potential transformer connections.

NOTE

Potential Transformers are not manufactured by Dranetz and are discussed here for informational purposes only.

Definition

A potential transformer (PT), also referred to as a voltage instrument transformer, provides the necessary step-down ratio to reduce the high voltage of circuits above 600 Vrms to a level for safe measurement. A PT also provides isolation and proper connections for instrument attachment.

Connections

PTs are usually fixed in position and require that the voltage probe(s) be connected to their terminal connections.

WARNING

Refer to the manufacturer's instructions, related to the PT, for exact information for probe connection for voltage monitoring. Do not exceed 600 Vrms input to the 4300 voltage inputs.

**ADVERTEN-
CIA**

Consulte las instrucciones del fabricante referentes a TP (transformador potencial), para la información exacta de la conexión de sonda a fin de monitorear el voltaje. No supere la entrada de 600 Vrms a las entradas de voltaje de 4300.

**AVERTISSE-
MENT**

Se reporter aux instructions du fabricant relatives au transformateur de tension (Potential Transformer - PT) pour obtenir les renseignements exacts sur la connexion de sonde utilisée pour la surveillance du courant. Ne pas dépasser l'entrée de tension efficace de 600 RMS dans les entrées de tension de 4300 volts.

WARNUNG

Genaue Informationen zur Meßfühlerverbindung für die Spannungsüberwachung entnehmen Sie bitte den Anleitungen des Herstellers (siehe Spannungsteilertransformator). Die Eingangsspannung von 600 V (Effektivwert) in die 4300 Spannungseingänge sollte nicht überschritten werden.

Connecting to a Potential Transformer (PT), Continued

Procedure

Follow these steps to connect voltage probes to a potential transformer.

Step	Action
1	Turn off power to the PT.
2	Connect the colored voltage probes to the channel inputs on the 4300's rear panel.
3	Connect the colored voltage probes to the PT's connections in accordance with the manufacturer's instructions.
4	Turn on power to the PT.

Scale factor

The scale factor of the PT must be accounted for in making accurate voltage measurements. Because the monitored output voltage of the PT is stepped-down (divided) from the original voltage, this ratio must be stepped-up (multiplied) by the 4300 when voltage computations are performed. The PT scale factor is usually mounted on the PT assembly and is entered into the 4300 on the scale factors screen (refer to page 6-11). Refer to the PT manufacturer's literature for the scale factor for the device you are using.

Connecting to a Current Transformer (CT)

Safety precautions

The following safety precautions apply to current transformer (CT) connections in addition to those safety precautions stated on page F-3.

- Never energize a CT with the secondary open.
 - Never disconnect the secondary of a CT with primary energized.
-

WARNING

Refer to the manufacturer's instructions related to the CT for exact information for connections for current monitoring. Do not exceed manufacturer's ratings.

ADVERTENCIA

Consulte las instrucciones del fabricante referentes a TC (transformador de corriente) para la información exacta de las conexiones a fin de monitorear la corriente. No exceda las capacidades nominales del fabricante.

ADVERTISSEMENT

Se reporter aux instructions du fabricant relatives au transformateur de courant (Current Transformer - CT) pour obtenir les renseignements exacts sur les connexions utilisées pour la surveillance du courant. Ne pas dépasser la puissance recommandée par le fabricant.

WARNUNG

Genaue Informationen zu Verbindungen für die Stromüberwachung entnehmen Sie bitte den Anleitungen des Herstellers (siehe Stromumwandler). Die Grenzwerte des Herstellers sollten nicht überschritten werden.

NOTE

Current Transformers are not manufactured by Dranetz and are discussed here for informational purposes only.

Description

Current transformers, also known as instrument transformers, reduce high level currents to low level currents so they can be safely monitored. These devices are similar to PTs used for voltage measurements in that both reduce values for safe measurement. The reduction, or step-down ratio, is stated as a scale factor that is used by the 4300 to step-up the measured value to its original value. Refer to page 6-11 for the procedure for entering scale factors.

Continued on next page

Connecting to a Current Transformer (CT), Continued

Types of CTs

There are single-phase CTs and polyphase CTs dependent on the source transformer used. Current reduction ratios vary widely and are also dependent on the source transformer used. Rating plates attached to the CT provide information as to the ratio and current limitations.

Connecting to an Isolated Current Transformer (ISO)

Introduction	Low current monitoring devices made by Dranetz are called isolated current transformers or ISO boxes. The Dranetz ISO box has a 5 A current range. See Scale Factors in Chapter 6 for information on scale factors. See Appendix A for ISO box description.
Safety precautions	<p>The following safety precautions apply to ISO box connections in addition to those safety precautions stated on page F-3.</p> <ul style="list-style-type: none">• Never energize an ISO box with the secondary open.• Never disconnect the secondary of an ISO box with primary energized.
WARNING	Physical injury or equipment damage could result if ISO boxes are improperly connected. Do not connect an ISO box between two conductors which are at different voltage potentials.
ADVERTENCIA	Podrían producirse lesiones físicas o daños al equipo si se conectan indebidamente las cajas del transformador aislado de corriente (ISO). No conecte una caja del ISO entre dos conductores que tengan distintos potenciales de voltaje.
AVERTISSEMENT	Une mauvaise connexion des transformateurs d'intensité isolés (ISO) peut provoquer des blessures corporelles ou des dégâts matériels. Ne pas relier les transformateurs ISO entre deux conducteurs de tensions différentes.
WARNUNG	Falsch angeschlossene ISO-Kästen (Isolierte Stromumwandler) können zu körperlichen Verletzungen oder Geräteschäden führen. Schliessen Sie einen ISO-Kasten nicht zwischen zwei Leiter mit unterschiedlichem Spannungspotential.
Connections to ISO box	The ISO box has terminal posts labeled X1 and X2 that are connected in series only with an ac current source. In normal connections, where phasing of current and voltages are important for power measurements, the X1 terminal is connected towards the source input line.

Continued on next page

Connecting to an Isolated Current Transformer (ISO), Continued

When connecting to CTs, the X1 terminal is normally connected to the H1 terminal of the device for correct reference phasing.

Where power measurements or voltage/current phase relationships are not important, the X1 and X2 terminals may be connected in series with the output device in any line (hot or return) or in any relationship of X1/X2.

Applications

ISO boxes can be used in a number of ways. These methods include:

- connecting them to the secondary of CTs for metering by the PP4300.
 - inserting them in series with the load current to measure low current values.
 - connecting them to a non-Dranetz clamp-on current transformer and using that CT to monitor current with the PP4300.
-

ISO box connection to a current transformer

The figure on the next page shows an ISO box connected from any current channel input to a permanently installed CT. The connection shown is made in the load return line for current monitoring only. Polarities of the ISO box and CT are kept in-phase by matching markings of X1 to H1. Scale factors of both devices must be multiplied together to get the resultant scale factor. Refer to Scale Factors in Chapter 6 for more information about ISO box scale factors.

Continued on next page

Connecting to an Isolated Current Transformer (ISO), Continued


CAUTION **DO NOT** exceed current limits of the ISO box.

PRECAUCION **NO** exceda los límites de corriente de la caja del ISO.

ATTENTION **NE PAS** dépasser les limites d'intensité du transformateur ISO.

VORSICHT Die aktuellen Grenzwerte für den ISO-Kasten sollten **NICHT** überschritten werden.

**ISO box
connection to a
CT**



Appendix G

PQLite Menu Structure

Overview

Menu description

The menu structure for the PQLite TASKCard is shown on the following pages. The menu structure is shown with Scope Mode as the leading element. This was done since Scope Mode appears as the first display screen following power up.


Menu structure aids

At the bottom of all screens are function keys which, when selected, permit further selection of multiple functions. The Menu Structure contains a listing of the important functions selectable under a function key. Scanning the listing under a major function can help you find other related functions and ways to access it.


In this appendix The following menus are shown in this appendix.

Topic	See Page
Scope/Meter Mode Menu	G-2
View Data Menu	G-3
Setup Menu	G-4


Scope/Meter Mode Menu



View Data Menu



Setup Menu



SELECT LANGUAGE is available in TaskCard V4.0 or higher

Index

Numerics

4300

- connecting to an ac power source 3-2
- installing TASKCard 3-3
- operational description 1-8
- optional accessories A-3
- physical description 1-6
- rear, right, and left panels 2-4
- resetting to factory configuration 5-8
- standard accessories 1-6
- top and front panels 2-2
- turning on monitoring 6-30

4300 Status Screen 5-12

658/4300 Current Probe Adapter Cable A-3

A

AC Power Source 3-2

Active Channels Screen 6-6

Alarm

- turning on and off 5-6

Alphabetic Entry Screen 5-3, 6-25

Apparent Power

- formula B-7
- viewing 4-4

Auto-Transfer to Memory Card Screen 7-4

B

Battery Pack

- replacement C-5
- safety precautions C-3
- specifications C-2

C

Calibration 1-7

Channel Selection Screen 4-2

Circuit Type

- selecting 6-8

Circuit Type Screen 4-4, 6-8

Index, Continued

Clear Event Memory Screen 5-7

CompactFlash Card, see Memory Card

Current

- ABC totals formula B-6

- viewing 4-4

Current Channels

- specifications B-4

- turning on and off 6-6

Current Connections

- current probe 3-14

- current transformer (CT) F-16

- guidelines 3-17

- isolated current transformer (ISO) F-18

- safety precautions 3-14

- verifying F-4

Current Phasors 4-7

Current Probes

- connecting 3-14

- selecting 3-17

- specifications for TR2500 B-8

Current Probes Screen 3-17

Current Transformers

- connecting F-16

- safety precautions F-16

- types of F-17

D

Date

- setting 5-5

Default Settings, see factory configuration

Delta

- floating, connection diagram F-10

- high-leg, connection diagram F-13

- one leg grounded connection diagram F-10

- open leg, connection diagram F-12

Describe Application Screen 6-4

Display, see LCD

DRAN-LINK™ Application, see Events

DRAN-VIEW® Application, see Events

Index, Continued

E

Easy Start

- description 1-8, 6-3
- monitoring combinations 6-4
- parameter thresholds 6-5
- using 6-3

Easy Start Screen 6-4

Edit Setup Menu 6-21, 6-22

Enter Site/File Name Screen 5-2

Error Messages

- descriptions E-4
- priority E-2

Event Activity Plot Screen 8-17

Event Descriptions

- miscellaneous events 8-21
- return to normal events 8-21
- threshold events 8-20

Event Details

- IEEE classifications 8-26

Event Details Screen 8-25

Event Report Screen 8-19

Event Waveform Data Screen 8-30

Event Waveform Screen 8-29

Event Waveforms

- 3-cycle waveform definition 8-28
- analysis of 8-30
- viewing 8-28, 8-34, 8-35

Events

- description 1-9
- downloading from 4300 to a computer 8-32
- downloading from internal memory 8-37
- downloading from memory card 8-37
- using DRAN-LINK™ to download data 1-1, 8-1, 8-34
- using DRAN-VIEW® to view data 8-1, 8-34, 8-35
- viewing complete event report 8-19
- viewing worst case 8-23

Index, Continued

F

Factory Configuration

- definition 5-8

- list of settings 5-8

- resetting unit to 5-10

Format Memory Card Screen 7-6

Frequency

- viewing 4-4

Frequency Synchronization

- definition 6-13

- entering internal frequency 6-15

- External CH D 6-13

- loss of 6-13

- stable signal 6-14

H

Handbook for Electrical Energy Management A-5

Handbook for Power Quality Analysis A-5

Harmonics

- viewing 4-8

Heavy Duty Cable Set A-5

I

IEEE Classifications 8-26

Input Channels

- definition 6-6

Interval for Timed Readings Screen 6-17

Isolated Current Transformers (ISO boxes) F-18

- applications F-19

- connecting F-18

- safety precautions F-18

L

Language

- select 1-1, 5-6

- selection screen 1-2, 5-6

LCD

- backlight auto-shutoff 5-6

- specifications B-3

Index, Continued

M

Measurement Cable Set 3-10

Memory

clearing 5-7

Memory Card

automatically saving data to 7-3

CompactFlash Card 1-10, A-9

description 1-9, 1-10, A-3, A-6

manually saving data to 7-5

SRAM Card 1-9, A-6

Memory Card Function Screen 7-5

Memory Card Readers

CompactFlash Card Reader A-3, A-6

SRAM Card Reader A-3, A-6

Memory Storage Mode Screen 7-2

Menu Structure G-2

Messages

descriptions E-3

priority E-2

Meter Mode

available parameters 4-6

description 1-8

viewing 4-4, 4-5

Monitoring

turning on 6-30

Monitoring Setup

changing setup name 6-25

definition 6-1

description 1-8

O

Optional Accessories A-3

P

Parameter Thresholds

enabling/disabling a parameter 6-24

editing 6-19, 6-20, 6-21, 6-22, 6-23, 6-24

entering a harmonic number 6-26

ranges 6-19

Index, Continued

- saving 6-26
- Phasor Screen 4-7, F-5, F-6
- Potential Transformers
 - connecting F-14
 - definition F-14
 - scale factor F-15
- Power Factor
 - formula B-7
 - viewing 4-4
- Power Measurements
 - delta, one leg grounded F-10
 - delta, open leg F-12
 - floating delta F-10
 - high-leg delta F-13
 - open leg delta F-12
 - single phase F-7
 - split phase F-8

R

- Reactive Power
 - formula B-7
 - viewing 4-4
- Read Data From Memory Card Screen 8-8
- Read Events From Memory Card Screen 8-5
- Replaceable Parts List D-1
- Reset to Factory Configuration Screen 5-10
- Reusable Shipping Container A-6
- Run Self-Test Screen 5-13

S

- Scale Factors
 - definition 6-10
 - entering 6-11
 - examples 6-10
 - for Dranetz equipment 6-10
 - range 6-11
 - when to use 6-10
- Scale Factors Screen 6-11
- Scope Mode
 - description 1-8
 - timeout 4-3

Index, Continued

- viewing 4-2
- Select Parameter to Plot Screen 8-12
- Self-Test
 - running 5-13
- Set Identical 3-Phase Thresholds Screen 6-22
- Set Individual Channel Thresholds Screen 6-23
- Set Programmable Features Menu 5-6
- Set Time and Date Screen 5-4
- Set Vertical Scale Screen 8-15
- Setup Menu Screen 6-29
- Setup Name
 - changing 6-25
- Single Phase
 - connection diagram F-7
 - TASKCard description 1-3, A-7
- Site Name
 - entering 5-2
- Site Status Screen 5-11
- Soft Carrying Case A-6
- Spare Parts D-1
- Specifications
 - computed parameters B-6
 - general B-2
 - interfaces B-3
 - measured parameters B-4
 - TR2500 current probe B-8
- Split Phase
 - connection diagram F-8
- Standard Accessories 1-6
 - measurement cable set 3-10
- Starting Date and Time Screen 8-6
- Sync Parameters Screen 6-16

T

- TASKCard
 - error messages when loading 3-6, E-4
 - installation 3-3
 - optional A-7
 - Single Phase description 1-3, A-7
 - Three Phase description 1-3, A-7
- Three Phase
 - TASKCard description 1-3, A-7

Index, Continued

Threshold Screen 6-21

Time

 setting 5-4

Time Plot Screen 8-11

 changing vertical scale 8-15

 selecting parameter to plot 8-12

 using horizontal zoom 8-13

Turn Monitoring On/Off Screen 6-30

V

Voltage

 ABC totals formula B-6

 viewing 4-4

Voltage and Current Harmonics Graph Screen 4-8

Voltage and Current Harmonics Text Screen 4-9

Voltage Channels

 specifications B-4

 turning on and off 6-6

Voltage Connections

 neutral to ground example 3-13

 potential transformers F-14

 single phase example 3-12

 verifying F-4

 voltage measurement cables 3-11

Voltage Phasors 4-6

Volt-Amps

 formula B-7

 viewing 4-4

Volt-Amps Reactive

 formula B-7

 viewing 4-4

W

Watts

 formula B-6

 viewing 4-4

Waveform Capture

 changing a setting 6-28

 combinations 6-27

 definition 6-27

 Select Wave key 6-17

Waveform Capture Screen 6-27, 6-28
Waveforms, see event waveforms
Worst Case Events Screen 8-23
Write Data to Memory Card Screen 7-6

Z

Zoom Screen 8-13

