

ABN 43 064 478 842

231 osborne avenue clayton south, vic 3169 PO box 1548, clayton south, vic 3169 t 03 9265 7400 f 03 9558 0875 freecall 1800 680 680 www.tmgtesteguipment.com.au

## Perform a complete reset of your ONX-620

Step 1: Restore unit to factory defaults Find this option under System Settings.

Step 2: Purge your unit of all previous data Instructional video available on our support site: <a href="https://www.tmgtestequipment.com.au/solutions/index.php?app=cms&ns=video&ref=n7hELJOcytI">https://www.tmgtestequipment.com.au/solutions/index.php?app=cms&ns=video&ref=n7hELJOcytI</a>

## Step 3: Reload software

Instructional video also available on our support site:
https://www.tmgtestequipment.com.au/solutions/index.php?app=cm
s&ns=video&ref=9ClCJFm0e-c

Step 4: Perform a Built-In Self-Test (BIST)
Instructional video also available on our support site:
<a href="https://www.tmgtestequipment.com.au/solutions/index.php?app=cms&ns=video&ref=zYIR7g4atDU">https://www.tmgtestequipment.com.au/solutions/index.php?app=cms&ns=video&ref=zYIR7g4atDU</a>

Step 5: Load Limit Plan (NBN Template)
Template and instructions available in our ONX-CATV tech
support website: https://tmg.com.au/onxsupport

Step 6: Test your unit at a known working location





