

VI.VI



HST-3000 – Battery Gauge Reset



freecall 1800 680 680
www.tmgtestequipment.com.au


HST-3000 – Battery Gauge Rest

- Ensure your unit is on charge and at 100%
- Press the hard key **“SYSTEM”** on your HST-3000



HST-3000 – Battery Gauge Rest

- Scroll to '**USER**' tab
- Press option 4, alternatively you can scroll down to the '**Reset Batt Gauge**' option



HST-3000 – Battery Gauge Rest

- A warning will appear asking you to ensure that your battery is already at 100% before resetting the gauge.
- Ensure your unit is on charge and at 100%.
- Select OK.
- **Battery Gauge Reset Complete!**



Require further support?



Please Call our Authorised **Distributor (TMG)** for Support: **1800 626 500**

Further support can also be found via the **TMG HST Support Portal:**

- Instructional Videos
- Upgrade Procedures
- More...

www.tmg.com.au/HSTSupport



HST Support Portal
HST3000-TMG-BV